# Assembly Instructions

Caution: You must read this before you proceed

#### Care & Maintenance



Not for commercial use. For residential use only.



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside. For indoor use only.



 Stains may be removed with mild soap solution and damp cloth.



• Children should not climb or jump on the furniture.




 Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.

Accent Chair N776P224504			
<u>Parts List</u>			
Label	Picture	Description	QTY
A		Back	1
В		Seat Cushion	1
C1		L Leg	1
C2		R Leg	1
D		Back Connection Rod	1
E		Front Connection Rod	1
<u>Hardware</u>			
Label	Picture	Description	QTY
1	(a)	Bolt (M6x55mm)	5
2	(a) (minimo)	Bolt (M6x18mm)	9
3		Threaded Rod	5
4		Washer (6×16×1.5mm)	13
5		Allen Wrench (5mm)	1
6		Allen Wrench (3mm)	1
7		Spare Leveller	1

#### Assembly Preparation

Before Beginning Assembly :







Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

#### Assembly Steps




This Accent Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Accent Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




Attach the Back Connection Rod (D) and Front Connection Rod (E) to L leg(C1) and R leg(C2) using the Washer (4),Bolt (2) with Allen Wrench (5) as pictured above.

Do not fully tighten the Bolts.




Attach the assembled Back (A) to frame with Leg using Threaded Rod (3) with Allen Wrench (6) as pictured above. Do not fully tighten the Bolts.



Attach the Seat Cushion (B) to the frame using Washer (4),Bolt (1) with Allen Wrench (5) as pictured above. Fully tighten the Bolts.


### Step 4



After checking the chair,If no problem,pls tighten all the Bolts. Stand the Chair up .

Place the chair on a LEVEL SURFACE to check for wobbles . Adjust the levelers to ensure chair stability

## Step 5



Your Chair is ready for use . This chair can only be used on a flat, level surface.