# **Assembly Instructions**

Caution: You must read this before you proceed

#### Care & Maintenance



• Not for commercial use. For residential use only.



 Prolonged exposure to rain may cause rusting which can stain floors.



• Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



• To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



 Do not write on furniture without a padded barrier to protect the surface.



• To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



 Stains may be removed with mild soap solution and damp cloth.




Keep away from sources of ignition.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.

#### Please look in Cushion for hardware packs

# **CHAIR**



Caution: This Chair is NOT a TOY.

Keep your child / children at bay in the process of assembly.


For turning the Chair and to prevent damage to the Chair, 02 persons may be needed to execute this action.

Parts List				
Label	Picture	Description	QTY	
Α		Rope Frame	1	
В		Seat Frame	1	
С	8	Left Front Leg	1	
D		Right Front Leg	1	
E	10	Back Leg	2	
F		Back Cushion	1	

G		Cushion	1	
Hardware				
Label	Picture	Description	QTY	
1)		Allen Wrench	2	
2	0	Bolt (M6*50mm)	3	
3	0	Bolt (M6*40mm)	5	
4		Bolt (M6*20mm)	4	
(5)		Bolt (M6*15mm)	5	
6	0	Flat Washer Rings	8	

# Assembly Preparation

Before Beginning Assembly





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




· Save all packaging until finished-

### Assembly Steps




Overview

This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise youself with the parts and steps before assembly.




Unpack and place all parts on a clean, non-marring surface.




Turn the Seat Frame (B) upside down on a safe, scratch-free surface. Align the bolt holes of the 2 Back Legs (E) with the Seat Frame (B). Install the 4 Bolts ( $\Im$ ) with 4 Washers ( $\Im$ ) through the mounting positions using Allen Wrench ( $\Im$ ), as shown above picture.

Fully tighten the Bolts.




Place the 2 Front Legs into the Seat Frame (B), making sure to place the Left Front Leg (C) and Right Front Leg (D) correctly, as shown above. Install the 2 Bolts (2) through the mounting positions using Allen Wrench (1), as shown above picture.

Do not fully tighten the Bolts.




Place the Rope Frame (A) into the Seat Frame (B), align the bolt holes. Install the 3 Bolts (4) with 3 Washers (6) through the mounting positions using Allen Wrench (1), as shown above picture.

Do not fully tighten the Bolts.



Stand the Chair up, use your hands to pull the 2 strings at the bolt holes of the Rope Frame (A) and the 2 Front Legs (C)-(D) as shown above, creating space for easy assembly. Install the 4 Bolts (5) through the mounting positions using Allen Wrench (1), as shown above picture.


Fully tighten the Bolts, both step 3 and step 4.



Use both hands to press the seat down into the floor. This will help the parts achieve full alignment.

Check for vibration and tighten the bolts one more time.

Place the Cushion (G) and Back Cushion (F) into the seat.



Your Chair is ready for use. This Chair can only be used on the flat, level surface.

On uneven surfaces, adjust the bases of the four legs.