Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



Not for commercial use. For residential use only.



Do not put hot items directly on furniture surface



• Do not clean furniture with harsh cleansers or polish.



• To obtain the longest liespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



• Children should not climb or jump on the furniture.



Do not write on furniture without a padded barrier to protect the surface.



• To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.




Stains may be removed with mild soap solution and damp cloth.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in the Seat Panel for hardware packs.

CHAIR




Parts List				
Label	Picture	Description	QTY	
А		Seat Panel	1	
В		Front Leg	2	
С		Back Leg	2	
D		Seat Cushion	1	

Hardware:

No.	Picture	Description	QTY
1		Bolt (M8x75mm)	9
(2)		Flat Washers (M8.5/20x2mm)	9
3	6	Spring Washer (M8/13 x 1.5mm)	9
4		Allen Wrench	1

Assembly Preparation

Before Beginning Assembly:













• Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

Assembly Steps




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Unpack and place all parts on a clean, non-marring surface.


Step 2



With the help of your adult partner, place the Seat Panel (A) with its underside skywards onto a clean, soft surface to avoid any scratch or damage to the product.

Attach the Front Leg (B) and Back Leg (C) to the Seat Panel (A) by using Bolts (1),

Flat Washer (②) and Spring Washer (③) with Allen Wrench (④) as shown in the picture above. Repeat the same process with the remaining Front Leg (B) and Back Leg (C). **Do not fully tighten the Bolts.**



Adjust Pre-installed Levellers high for balance

Inspect it and make sure all parts are adequately connected.

Turn the Chair right side up.

Gently and gracefully, sit onto the Chair.

This will help to align all the parts at all joint areas.

Then get off the Chair and in a sequential manner, gradually tighten all Bolts at all joints until evenly connected.

If there are still wobbles, loosen the Bolts and execute this same process.

Place the Seat Cushion (E) by affix the Magic Tape Straps on the Seat Panel (A) as shown above.

Adjust Pre-installed Leveler height for balance as shown above.

WARNING!! IF CHAIR IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT. Your Chair is ready for use.

This Chair can only be used on a flat, level surface.