CARE INSTRUCTIONS

BEFORE USE

- Foam is sensitive to temperature. When exposed to colder temperatures your Bean bag will become firmer. Your body heat will help the foam soften.
- External heat source, not recommended on the Bean Bag doing so will damage the Bean Bag.
- New foam may initially have a slight odor: it is completely harmless and will dissipate over a short time with regular use.

WASHING CARE

- Pre-wash the zippered cover before first use.
- Wash zippered cover separate from other items as zipper may cause damage to clothing or linens
- Wash the zippered cover in cold water using a non-chlorine bleach detergent on a gentle cycle with cold water rinse.
- The Bean Bag can be spot cleaned with mild detergent by hand wash only; do not soak or machine wash the foam. Rinse with warm water.

DETERGENT

 Use a mild liquid detergent, preferably non alkaline, without added bleach or whiteners.


DRYING CARE

- Tumble dry zippered cover on low heat.
- Never use a high heat setting or over dry;
 this will weaken the fibers, cause shrinkage
 and or shorten the life of the cover.
- After spot cleaning the Bean Bag dry at room temperature away from heat or light.
 Do not machine wash or dry.

SETUP INSTRUCTIONS




Have a friend help to remove your beanbag components from the box.




Open the fabric cover completely, and slide it over the Foam stuffing. The zipper should be oriented on the bottom.



Take the bag of Foam stuffing, and unroll it from its protective outer plasting wrapping revealing it inside its inner wrapping.



Adjust the stuffing inside the case, breaking up any lumps of Foam, then zip to close. Your beanbag will now need time to expand to its maximum size - this can happen as quickly as 6 hours, and can take up to 7 days. Then, enjoy!



Flatten the Foam stuffing, leaving it within its inner wrapping. Then remove the wrapping by cutting it with scissors.