## **Assembly Instructions**

CAUTION: You must read these Assembly Instructions before you proceed.

### Care & Maintenance



• Not for commercial use. For residential use only.



• Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



 To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



• Do not write on furniture without a padded barrier to protect the surface.



 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine.
 Whenever possible cover the product and /or place under patio or awnings.




• Stains may be removed with mild soap solution and damp cloth.



• Dust and pick-up spills using a clean, non-colored, lint- free cloth.

Please look in the Leg Panel for hardware packs.

# **CHAIR**





Parts List:				
Label	Picture	Description	QTY	
А		Right Leg Panel	1	
В		Left Leg Panel	1	
С		Upper Back Slat	1	
D		Lower Back Slat	1	
E		Seat Panel	1	
F		Seat Cushion	1	

Hardware:				
No	Picture	Description	QTY	
1)		Screws (M6*70mm)	7	
2		Allen Wrench	1	

### **Assembly Preparation:**

Before Beginning Assembly:







Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-



Assemble on a clean non-marring surface (packing foam)-





Save all packaging until finished-

# Assembly Steps: Overview: Lower Back Slat (C) Right Leg Panel (A) Seat Cushion (F)

This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.


**FRONT FACING** 





With the help of your adult partner, put the tenons of the Seat Panel (E) and Upper Back Slat (C) to the mortises of Right Leg Panel (A) as shown above then secure by using Screws (1) and Allen Wrench (2).


Do not fully tighten the Screws.



With the help of your adult partner, attach the Lower Back Slat (D) into the Right Leg Panel (A) as shown above.

Attach the mortises of Left Leg Panel (B) to the tenons of Upper Back Slat (C), Lower Back Slat (D) and Seat Panel (E) and then secure by using Screws (1) and Allen Wrench (2) as shown above.

Do not fully tighten the Screws.



Inspect it and make sure all parts are adequately connected.

Gently and gracefully, sit onto the Chair.

This will help to align all the parts at all joint areas.

Then get off the Chair and in a sequential manner, gradually tighten all Screws at all joints until evenly connected.

If there are still wobbles, loosen the Screws and execute this same process.

Adjust Pre-installed Leveler height for balance as shown above.

# WARNING!! IF CHAIR IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Your Chair is ready for use.

This Chair can only be used on a flat, level surface.