

ASSEMBLY INSTRUCTIONS:

6575 GAME TABLE





6575 GAME TABLE

ASSEMBLY INSTRUCTIONS


Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604 during business hours, email parts@comfortpointe.com.

Attention : Veuillez Lire Toutes Les Instructions Avant De Commencer L'assemblage De Ce Produit. Les Pièces Sont Lourdes. Pour Éviter Toute Blessure Et Pour Vous Assurer Que Le Produit N'est Pas Endommagé Pendant L'assemblage, Nous Vous Recommandons De Faire Appel À Une Ou Plusieurs Autres Personnes.

Cuidado: Favor De Leer Todas Las Instrucciones Antes De Ensamblar Su Producto. Estas Piezas Son Pesadas. Para Prevenir Heridas Personales Y Asegurar Que Su Producto No Sea Dañado Mientras Es Ensamblado, Se Recomienda La Asistencia De Una O Más Personas.



Important: Use hand tools for assembly. Power tools can lead to over-tightening and damage.

6575 GAME TABLE

Parts List


CODE	DESCRIPTION	QTY	CODE	DESCRIPTION	QTY
A1 Table Top Pad		2 pcs	D1 Legs		4 pcs
B1 Table Top		1 pc	E1 Connecting Plate		4 pcs
C1 Table Base		2 pcs	F1 Metal Cross Brace		2 pcs


6575 GAME TABLE

Hardware List

CODE	DESCRIPTION	QTY
1 Bolt M8x30mm		24 pcs
2 Bolt M8x20mm		8 pcs
3 Flat Washer Ø16		32 pcs
4 Lock Washer Ø13		32 pcs
5 Allen Wrench		1 pc








DO NOT TIGHTEN BOLTS YET


TIGHTEN ALL BOLTS NOW

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604, email: parts@comfortpointe.com.




IMPORTANT WARNING: REVERSIBLE GAME TOP

- 1. **CAUTION**: To prevent injury, always keep your fingers away from the hinge area when opening or reversing the game top. Ensure that all parts of your hands are clear of the hinge gap to avoid pinching or crushing.
- 2. This game top is designed to fold in one specific direction only. Please follow the directional arrows when folding to ensure proper alignment and prevent hinge stress




If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604, email: parts@comfortpointe.com.





If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.336.861.0604, email: parts@comfortpointe.com.



*****IMPORTANT MESSAGE******

Please check to insure you have received all parts listed on the instruction sheet provided. If you did not receive all parts or received damaged parts please email or call the following:

Email: Parts@comfortpointe.com

Phone: 336-861-0604 Contact: Parts Department

Office hours:

8am to 4pm EST Mon-Thur 8am to 3pm EST Friday

You will need to provide the item number purchased, your reference number, and identify which part is missing/damaged, all parts orders are considered priority.

Thank You