ASSEMBLY INSTRUCTIONS BATH VANITY-CABINET


SKU - N759P293646



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


Before Installation


Impor ant - Please read these instructions fully before staring assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions








Part Lists N759P293646			
1	2		
Side Panel (L) - 1pc	Side Panel (R) - 1pc		
3	4		
Mid Panel - 1pc	Mid Frame - 1pc		
5	6		
Top Front Crossbar - 1pc	Door Stopper - 1pc		
7	8		
Bottom Front Crossbar - 1pc	Bottom Rear Crossbar - 1pc		
Top Rear Crossbar - 1pc	Right Rear Crossbar - 1pc		
Large Drawer Face- 1pc	Side Drawer Panel (L) - 3pcs		
13	14		
Side Drawer Panel (R) - 3pcs	Bottom Large Drawer Panel - 1pc		





Hardware Lists N759P293646		
A	В	С
Ø8*30mm	Ø6*32mm	Ø14.5*9.5mm
Wood dowel (18pcs) + 1pc	Three in on bolts (24pcs) + 1pc	Three in one locks (24pcs) + 1pc
D	Ø13xM6*30mm	F K4mm
Damping hinge (4 sets)	Hex-Head bolt (8pcs) + 1 pc	Allen key (1pc) + 1pc
G	Н	45*12*1mm 45*17*14mm
Flat washer (8 pcs)+1Pc	Slide rail (8 pcs)	Plastic Door Magnet (2 sets)
	K	
Ø8xØ3.5*15mm	Ø8xØ3.5*12mm	Ø10*10mm
Round head screw (4pcs)	Flat head screw (30pcs) + 1pc	Plastic Canopy (16pcs) + 1pc
M <i>⊗ Station of the light of the ligh</i>	N	O
Round head screw (18pcs) + 1pc	Handle (2pcs)	Handle (5pcs)
P Ø8xM4*20mm	Q	R
Handle screw (12pcs)	Anti fall Hardware (2 sets)	L Bracket (1pc)
S (6*20mm		
Ø6*20mm Wood dowel (1pc)		



































HINGE ADJUSTMENTS



1 Sideways / Tilt adjustment

Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet

(2)(4) Height adjustment

While supporting the weight of the door, turn the screws clockwise to move the door up anticlockwise to move the door down

(3) Forward and back adjustment

