Assembly Instructions

CAUTION: You must read this before you proceed.

Care & Maintenance



Not for commercial use. For residential use only.



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside. For indoor use only.



 Stains may be removed with mild soap solution and damp cloth.




Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look the hardware pack in Bottom Shelf

TABLE



CAUTION: This Table is NOT a TOY.

Keep your child / children at bay in the process of assembly.


For turning the Table and to prevent damage to the Table, 02 persons may be needed to execute this action

Part List				
Label	Picture	Description	Q.ty	
A		Table Top	1	
В		Bottom Shelf	1	
C	18	Middle Shelf	1	
D		First Leg	2	
E		Second Leg	2	
F	0 0	Middle Leg	2	

<u>Hardware</u>					
Label	Picture	Description	Q.ty		
1		Bolt (M6*40mm)	18		
2		Lock washer	18		
3		Flat washer	18		
4	H) DOMESTIC HIS	Screw (M3*35mm)	6		
5		Allen Wench	1		
6		Screw Drive	Not Provided		

Assembly Preparation

Before Beginning Assembly:

















- Read instruction, cover to cover-
 - Have 2 adults on hand for assembly-
 - Do not assembly on flooring or carpet-
 - Assemble on a clean non- marring surface (packing foam)-
- Save all packaging until finished-


Assembly Steps OVERVIEW Table Top (A) First Leg (D) First Leg (D) Middle Leg (F) Second Leg (E) Middle Shelf (C) Bottom Shelf (B) Step 1

Unpack and place all parts on a clean, non-marring surface.


Step 2 D




Put the Table Top (A) upside down on a soft surface. Position the First Leg (D), Second Leg (E), Middle Leg (F) to the Table Top (A) as shown above picture.




Attach the First Leg (D), Second Leg (E), Middle Leg (F) to the Table Top (A) using Bolt (1), Lock Washer (2), Flat Washer (3) and Allen Wrench (5) and tighten bolts.




With assistance from your adult partner, put the Wooden Dowel on the Middle Shelf (C) to the hole on the Legs.



With assistance from your adult partner, repeat step 3 and step 4 to attach First Leg (D), Second Leg (E) and Middle Leg (F) to the Table Top (A) and Middle Shelf (C) using Bolt (1), Lock Washer (2), Flat Washer (3) and Allen Wrench (5) and tighten bolts as shown above picture.



To secure the Middle Shelf (C) to the Legs using Screw (4) and Screw Driver (6) (not provided) and tighten Screw as picture.



With assistance from your adult partner, attach Bottom Shelf (B) to the Legs using Bolt (1), Lock Washer (2), Flat Washer (3) and Allen Wrench (5) and tighten bolts as shown picture.

With the help of your adult partner, stand the Table up.

Exert pressure floor wards, onto the Table with both your hands.

This pressure will help the Legs and Table Top reach full alignment status.

Check for wobbles on a LEVEL surface.

If no wobbles are found proceed to tighten the Bolts in a sequential manner, until evenly secured. When tightening the Bolts tighten sequentially.


Do not tighten any Bolt fully and then move on towards the next one.

If there are still wobbles, loosen the Bolts and execute the same above process.

WARNING!! IF TABLE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Your Table is ready for use.

This Table can only be used on a flat, level surface.



COMPLETED