

WARNING!!

Children have died from furniture tipover. Tip restraints have been included with this product; you must install the tip restraints according to these instructions in order to minimize the risk of furniture tipping.

NEVER allow children to climb or hang on furniture, including drawers or cabinet doors.

In addition to installing the restrains, to help prevent tip-over












1. **NEVER** put a TV or other heavy objects on top of this product".
2. Do not stand on the product

 WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none">-ALWAYS install anti-tip device provided.-NEVER put a TV on this product.-NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.-NEVER open more than one drawer at a time.-Place heaviest items in the lowest drawers. <p><i>This is a permanent label. Do not remove!</i></p>
	

Assembly Instructions


Caution : You must read this before you proceed




Care & Maintenance










- ⊘  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ⊘  • Do not place furniture under direct sunlight.
- ⊘  • Do not place furniture near heating or cooling vents.
- ⊘  • Do not write on furniture without a padded barrier to protect the surface.
- ⊘  • Do not place furniture outside . For indoor use only.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ⊘  • Children should not climb or jump on the furniture.
- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.

CONSOLE TABLE













<u>Parts List</u>			
Label	Picture	Description	QTY
A		Top board	1
B		Leg	4
C		Shelf board	1

Hardwares			
Label	Picture	Description	QTY
①		Hex bolt (M8*35mm)	13
②		Flat washer	13
③		Adjustable leveling glide	4
④		Hex wrench	1
Tipover Restraint Device Hardware			
⑤		Anti-Tipping webbing	2
⑥		expansion plug	2
⑦		Long screw(M4*40mm)	2
⑧		Short screw (M4*12mm)	2
⑨		Flat washer	4

Assembly Preparation

Before
Beginning
Assembly:



①		x12	⑤		x2
②		x12	⑥		x2
③		x4	⑦		x2
④		x1	⑧		x2
			⑨		x4



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This table has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Attach legs(B) to top board(A) with hex bolt(①) and flat washer(②)

Step 2




Follow step 1, attach the rest 3 legs(B) to top board (A) with hex bolt(①) and flat washer(②)

Step 3




Align shelf board (C) with the pre-drilled holes on the 4 legs.

Step 4



Attach shelf board (C) to legs (B) with hex bolt (①) and flat washer(②).


Step 5



③x4

Screw adjustable leveling glide (③) on the legs(B).

Step 6




⑤x2

⑧x2

⑨x2


Align with the pre-drilled hole on back of the top board(A) ,install the Anti-Tipping webbing (⑤) on on back of the top board (A) with short screw (⑧) and washer (⑨) .

Step 7



Drill holes on the wall, insert expansion plugs(⑥) into the holes, align with the expansion plugs (⑥) , install the Anti-Tipping webbing (⑤) with long screw (⑦) and flat washer (⑨) .

Step 8



The console table is ready for use

"Questions & Answers about Proposition 65

- What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm. These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals.

Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water.

Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

- What types of chemicals are on the Proposition 65 list?

The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust. "