







Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.


Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: service@cozayh.com

Website: www.cozayhhome.com


ITEM		PART		DESC.		QTY	
A		Table Top	1	C		Wood Base	1
B		Wood Legs	4	D		Screws (Ø6×30mm)	8
E		Allen Wrench	1	F		Flat Washers	8

STEP 1




Flip the table top A upside down. Attach leg B to the bottom of table top A with bolts and flat washers as shown.

STEP 2



Attach base C to the end of leg with screws and flat washers as shown.

STEP 3



Finished product. Please make sure all the screws are fully tightened before using this table.

! WARNING

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard - Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 25 Lbs. Do NOT overload.



COZAYH HOME