











Assembly Instructions.


Caution: You must read these Assembly Instructions before you proceed.

Care & Maintenance:

⊘ 	Not for commercial use. For residential use only.
⊘ 	Prolonged exposure to rain may cause rusting which can stain floors.
⊘ 	Do not put hot items directly on furniture surface.
⊘ 	Do not clean furniture with harsh cleansers or polish.
✓ 	To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
⊘ 	Children should not climb or jump on the furniture.
⊘ 	Do not write on furniture without a padded barrier to protect the surface.
✓ 	To obtain the longest lifespan of your outdoor products , avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
⊘ 	Stains may be removed with mild soap solution and damp cloth.
✓ 	Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look into the Seat Panel for hardware packs

Rocking Chair













Caution: This Chair is NOT a TOY.

Keep your child/children at bay during the assembly process.


Whenever lifting or moving the Chair and to prevent damage to the chair, two adults may be needed to execute these actions.

Parts List

Label	Picture	Description	QTY
A		Seat	1
B		Wood Leg (Left)	1
C		Wood Leg (Right)	1
D		Wooden Base	2
E		Seat Cushion	1
F		Back Cushion	1
1		5pcs (Extra 1pce) Bolt (M6x80)	
2		5pcs (Extra 1pce) Washer (M6x16)	
3		4psc (Extra 1pce) Screw (M7x70)	
4		2pcs Allen Wrench (M4)	
Page 3 OF 6			

Assembly Preparation

Before Beginning Assembly




- Read instructions, cover to cover.



- Have 2 adults on hand for assembly.



- Do not assemble on flooring or carpet.




- Assemble on a clean non-marring surface (packing foam).



- Save all packaging until finished.


Assembly Preparation

Overview




This Rocking Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Rocking Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Place all the parts on a clean, non-marring surface.
Attach Seat (A) and Wooden leg-Left (B) together.
Lock in the mounting position, using Bolt(1), Washer(2) and Allen Wrench (4).
Do not fully tighten the Bolts

Step 2



You will now have the Seat (A), Wooden leg (B).
Insert the Wooden leg-Right (C).
Lock in the mounting position, using Bolt(1), Washer(2) and Allen Wrench (4).
Do not fully tighten the Bolts

Step 3




Next, install Wooden Base (D)

Lock in the mounting position, using Screw (3) and Allen Wrench (4).

Do not fully tighten the Bolts

Step 4



Next, install the Seat Cushion (E)& Back Cushion (F) into the Chair.

Place the Chair on a **LEVEL SURFACE**.

Inspect it and make sure all parts are adequately connected.

Gently and gracefully, sit into the Chair. This will help to align all the parts at all joint areas.

Then get off the chair and proceed to tighten the Bolts in a sequential manner.

When tightening the Bolts tighten sequentially.

DO NOT tighten any Bolts fully and then move on towards the next one. If there are still wobbles loosen the Bolts and execute this same process.

Your Chair is ready for use.

This chair can only be used on flat, level surface.