




Product Assembly Instructions

LCKSDIWATOP / LCKSDIWABA - KLARISSA DINING TABLE

PART LIST



A : TABLE TOP x1



B : TABLE LEG x4

HARDWARE LIST



C : JCBB SCREW M8 x 70MM x8



D : SPRING WASHER 5/16" x8





E : FLAT WASHER 5/16" x8



F : M5 ALLEN KEY x1

STEP 1



Place Table Top (A) face down, on a clean smooth surface.

ASSEMBLY IS COMPLETE

