









Assembly Instructions


Caution : You must read this before you proceed.

Care & Maintenance





- ⊘  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ⊘  • Do not place furniture under direct sunlight.
- ⊘  • Do not place furniture near heating or cooling vents.
- ⊘  • Do not write on furniture without a padded harrier to protect the surface.
- ⊘  • Do not place furniture outside. For indoor use only.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ⊘  • Children should not climb or jump on the furniture.
- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.




Please look in carton for hardwear packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.

Recliner




Parts List

Label	Picture	Description	QTY
A		BACKREST	1
B	 L R	Wing	2
C		Chair base	1
D		Pillow	1

Parts List			
Label	Picture	Description	QTY
E		POLE	1
F		LEG	1
J		POWER SUPPLY	1

Assembly Steps




This recliner has multiple parts and may require up to 10 minutes to assemble. To give you an overview of the recliner parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly

STEP 1




A




L

R


B




C



D



E




F



J


Place all Parts on a clean and flat surface

STEP 2




Assemble the pole(E) into the leg(F)

STEP 3




Flip the Chair base(C) and assemble the leg(F) with the pole(E) into the mounting hole at the bottom of the Chair base(C)

STEP 4




Assemble the backrest(A) to the chair base(C)

STEP 5




Assemble the Wing(B) to the backrest(A)

STEP 6




Put the Pillow(D) on the chair base(C)

STEP 7




Connect the power cord and plug in the power supply

STEP 8




Smooth down the fabric flap on the chair backrest(A).Run your hands down both sides of the flap, from top to bottom,allowing the magic tape to adhere to the flap under the seat of the chair.

STEP 9




Your Recliner is ready for use.This Recliner can only be used on a flat,level surface.

Disassembly




Disassembly Note: Open the flap on the chair Backrest(A), use a screwdriver (Do not use fingers) pressing outward on the metal ear on the preattached Metal Bracket on one side of the Chair Base(C), with assistance of you adult partner to keep the Chair Base(C) in place, pull out the Chair Backrest(A) upward at the same time, repeat the same step for another side. Then the Chair Backrest(A) can be taken out.

Warning!!



correct to use



incorrect to use



incorrect to use



incorrect to use



incorrect to use



incorrect to use

Always leave the chair in an upright and closed position after use. Keep hands and feet clear of the footrest mechanism and any gaps. Do not allow children to play on the chair. Do not lean to side to pick up anything while sitting on the chair. Do not sit on the arms. Do not stand up when the recliner open. Only the occupant should operate the chair.

User Instructions.

Glider Recliner With Swivel

Please read the Instruction Manual below carefully before use.

This is a Recliner Chair. At anything in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion, and swivel motion as well.

Supervise children, when in use of this Recliner.

To get into the Recline position:

Sit in your seat.

Press and hold the open button on the outside of the right armrest. Enter a fully tilted position.



Button control can stay and tilt at any position.

Press and hold the close button on the outside of the right armrest. As the footrest slowly retracts, the backrest will also slowly return to its upright position.

Where necessary, use your arms help lift/push yourself out of the seat.

