
ASSEMBLY INSTRUCTIONS BATH VANITY-CABINET N710P257401



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED




* Please assemble on a clean soft surface to avoid damage.














(Not included)

(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE




Please do not return this product to the retailer!!


We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


Detail View





Identifying the Hardware-Identify the hardware using the illustrations below.





Hardware Lists - N710P257401		
A	В	
Ø8*20mm	K4mm	Ø13x1/4*25mm
Wood dowel (10pcs)	Allen key (1pc)	Hex-Head bolt (4pcs)
D	E	F
		(1)
Ø13x1/4*30mm	Ø13x1/4*40mm	Ø13x1/4*50mm
Hex-Head bolt (8pcs)	Hex-Head bolt (2pcs)	Hex-Head bolt (8pcs)
G	H	
Ø8xØ4*15mm	Ø6xØ3*15mm	Ø7xØ3.5*12mm
Flat head screw (9pcs)	Flat head screw (2pcs)	Flat head screw (12pcs)
J €)********* Ø6xØ2*12mm	45*12*1mm 45*17*14mm	
Round head screw (4pcs)	Plastic Door Magnet (1set)	Shelf Pin (4pcs)
M	N	
Damping hinge (2pcs)	Handle(1pc)	Anti Tip Kit (2sets)
Ø6xØ3*15mm Round head screw (2pcs)		
<u></u>		
5		



























HINGE ADJUSTMENTS



(1) Sideways / Tilt adjustment

Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down

(3) Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw clockwise to decrease the gap between the door and the cabinet anticlockwise to increase the gap between the door and the cabinet

