Assembly Instructions

Caution: You must read these Assembly Intructions before you proceed

Care & Maintenance











• Do not clean furniture with harsh cleansers or polish.



 To obtain the longest lifespan of your outdoor products, minimizing minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



 Do not write on furniture without a padded barrier to protect the surface.



 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



 Stains may be removed with mild soap solution and damp cloth.




Keep away from sources of ignition.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth. Please look under the Seat Panel for hardware packs.

Chair



CAUTION: This Chair is **NOT** a TOY.

Keep your child / children at bay during the assembly process.

Two adults may be needed to execute these actions.


Whenever lifting or moving the Chair and to prevent any damage to it.

Parts List				
Label	Picture	Description	QTY	
А		Left Leg Panel	1	
В		Right Leg Panel	1	
С		Backrest Panel	1	
D		Seat Panel	1	
E		Support Bar	1	
F		Seat Cushion	1	
G		Back Cushion	1	

Hardware				
Label	Picture	Description	QTY	
1)		Hex Screw (M6x30mm)	5	
2		Bolt (M6x30mm)	7	
3		Bolt (M6x40mm)	5	
4		Connecting Cap (M6x15mm)	7	
5		Allen Wrench (M4)	2	

Assembly Preparation

Before Begining Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



· Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-


Assembly Steps



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.




Unpack and place all parts on a clean, non-marring surface.



Place the Left Leg Panel (A) and Backrest Panel (C) with its inner side face skywards onto a clean, soft surface to avoid any scratches or damages to the product. With the help from your partner, stand the assembled Left Leg Panel (A) and Backrest Panel (C) standing as shown in picture above.


Align the Mounting Position of Left Leg Panel (A) into the Mounting Position of Backrest Panel (C) as shown above.

Then, affix the Backrest Panel (C) with Left Leg Panel (A) by using Bolt (2) and Connecting Cap (4) with Allen Wrench (M4) (5).



Align the Mounting Position of Right Leg Panel (B) into the Mounting Position of Backrest Panel (C) as shown above.


Then, affix the Backrest Panel (C) with Left Leg Panel (B) by using Bolt (2) and Connecting Cap (4) with Allen Wrench (M4) (5).



Align the Mounting Position of Left Leg Panel (A) and Right Leg Panel (B) into the mounting positions of Support Bar (E).

Then, affix the Left Leg Panel (A) and Right Leg Panel (B) to Support Bar (E) by using Bolt (③) with Allen Wrench (M4) (5).






Put Seat Panel (D) on the Seat Frame.

Align the Mounting Position of Left Leg Panel (A), Right Leg Panel (B) and Support Bar (E) into the mounting positions of Seat Panel (D) as shown in picture above.


Then, affix the Left Leg Panel (A), Right Leg Panel (B) and Support Bar (E) to Seat Panel (D)

by using Hex Screw (1) with Allen Wrench (M4) (5).




Put Seat Cushion (F) on the Chair.






Tight ropes under the Seat Cushion (F) on the Seat Panel (D).

Step 9



Put Back Cushion (G) on the Chair.



Turn the **Chair** right side up.

Inspect the Chair and make sure all parts are adequately connected.

In a sequential manner, tighten ALL Screws and Bolts at ALL joints.


With assistance from your adult partner, adjust the **Levellers** to the desired height, to avoid wobbles.

CAUTION: When tightening these screws and bolts, tighten sequentially.

<u>DO NOT</u> tighten any screw or bolt fully and then move towards the next one.

This could cause the frame to warp.

WARNING: IF THE CHAIR IS NOT STABLE, IT COULD LEAD TO DAMAGE IN THE CHAIR.



Your Chair is ready to use.

This Chair can only be used on a flat, level surface