


# USER'S MANUAL

## RILEY SERIES KIDS BOOKCASE



**WARNING:**  
Assembly by an adult.

## Guide of Manual

- ★ Thanks for your choice. **We will do our best to provide customer service for everyone.**
- ★ Please check to make sure all parts are included as stated when you unpack. If there are parts missing or wrong, please contact us, **we will expeditiously provide reissue accessories, compensation or other services.**
- ★ Instruction should be read carefully. But the manual may not cover every detail of all possible situations and steps. **Please contact us if further information and help are needed. We will respond in a timely manner.**
- ★ **Please be patient that the other items are on the way if you buy more than one product.**

## Warning

- It's kindly advised to assemble this product on a carpeted floor to protect it from being scratched.
- Small parts are included. Please keep the product away from children while assembling. Do not let children play or jump on the product. Do not stand on the item or use as a step ladder.
- Please pay attention to the sharp corners during assembly. We recommend the use of gloves to prevent the undesired injury.
- Prior to use, please check to see if there's any loosening screw or part. Make sure that each screw and part is correctly installed and securely fastened.
- Power tools are usually not required. Please at a low gear if you need.

## Care and Maintenance

- Use a soft, clean cloth that will not scratch the surface when dusting.
- There's no need to use furniture polish. If you need, test it first in an inconspicuous area. Using solvents of any kind on your furniture may damage the finish. Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately. Gently blot the spill with a soft clean cloth to avoid rubbing.

## Further Advice about the Furniture Care

- It is best to keep your furniture in a climate-controlled environment.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Following these important and helpful tips will help retain your furniture's performance even when it ages.
- Periodically (every 90 days) make sure the screws are fully tightened.

**MATERIAL: MDF**

**MAX WEIGHT CAPACITY: 22LBS/SHELF 44LBS/BOTTOM PANEL**





















**⚠ ATTACH THE ITEM TO THE WALL IS NECESSARY IN ORDER TO AVOID ACCIDENTS.**



















## Parts List & Assembly Instruction


1. Make sure all parts are in the package.

2. "+" in below list indicates that additional pieces are replacement parts.

UNIT:MM

①×1pc 	②×1pc 	③×1pc 	④×1pc 
⑤×2pcs 	⑥×1pc 	⑦×1pc 	⑧×1pc 
⑨×1pc 	⑩×1pc 	⑪×1pc 	⑫×3pcs 
⑬×1pc 	⑭×1pc 	⑮×1pc 	⑯×4pcs 
⑰×1pc 	⑱×1pc 	⑲×2pcs 	⑳×1pc 











UNIT:MM									
									
M6×35		Ø15x10		Ø6x30		M4x35			
A	x41+4pcs	B	x42+4pcs	C	x7pcs	D	x20+2pcs	E	x1pc
									
15x10		M3x12				Ø4		20x200	
F	x8pcs	G	x9pcs	H	x6pcs	I	x2pcs	J	x1pc
									
Ø6x30		M4x35		M5 4.5x10				M4x10	
K	x1pc	L	x1pc	M	x1pc	N	x4pcs	O	x16+1pcs
									
L=500		Not Included		Not Included					
P	x1pc	Drill		Hammer					





1

Screw (A) into the holes of the boards numbered ① ② ③ ⑥ ⑦ ⑬ ⑱ for later use.



Tips: The thick lines in the figure are the groove lines on the board for identifying the correct direction during installation.





2





3



4





5









6





7




8




9






- 10 The boards 14 and 15 need to be fully pushed in.





11





		
M x1	B x10	C x3



12




13




14




15







16



17












		
M	F	G
x1	x8	x8

19

For safety reasons, please be sure to attach the product to the wall to avoid accidents!  
Install as follows:



- 1) Drill a hole with electric drill on the wall.
- 2) Hammer the (K) into the hole.
- 3) Fix (J) to the back of the product by tightening (G) to the board (4) through (I) and (J).
- 4) Fix (J) to the wall by tightening (L) to the (K) through (I) and (J).




					
M	J	I	K	G	L
x1	x1	x2	x1	x1	x1





20



21 The board 20 needs to be fully pushed in.



22



23

