
Installation Instruction



Product name

4 Door Cabinet

Ver.1.0 20240821

Assembling

What you need

- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips head screwdriver



Weight Limitation






What's included

Code Description		
A	Cam Bolt M6X35mm	30
В	Cam Lock 15X10mm	30
С	Wooden Dowel M6X30mm	16
D	Screw M4X35mm	8
Е	Big Hinge	4
F	Screw M4X14mm	6
G	Nylon Strap	2
Н	Anchor M6x30mm	2
ı	Plastic Corner Support	16
J	Screw M3X16MM	16
K	Small Hinge	4
L	Screw M4X14mm	52
М	Metal Pin	1
N	Plastic Door Catcher	2
0	Bolt M4X22mm	8
P	Handle	4
Q	Metal Support	8

The hardwares



IMPORTANT:


- 1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. Must need 2 people to assemble this product.





Included Accessories

Code	Description	Qty
1	Cabinet Top	1
2	Left Side Panel	1
3	Right Side Panel	1
4	Left Back Leg	1
5	Left Front Leg	1
6	Right Back Leg	1
7	Right Front Leg	1
8	Bottom Panel	1
9	Lower Front Stretcher	1
10	Shelf	2
11	Middle Division Panel	1
12	Vertical Back Stretcher	2
13	Back Panel	4
14	Middle Foot	1
15	Left Door of Left Side	1
16	Right Door of Left Side	1
17	Left Door of Right Side	1
18	Right Door of Right Side	1


The Accessories



































































































































Is your cabinet door looking crooked or unevenly spaced? (Cont.)

If you're still having trouble lining everything up, your next step should be to try to adjust the feet slightly to square up the cabinet & doors. Follow the illustrations below:

If the right door appears to be hanging low, you can adjust the adjustable leveler on the front right until the door is better aligned.



Proper Use

DO NOT use for commercial purposes

DO NOT use as a step stool or stand on table

DO NOT put hot serving liquid directly on the table top

DO NOT leave spilled liquid on the table top

DO NOT use table if damaged

DO NOT exceed weight limit

DO NOT make temporary repairs

DO NOT use outdoor

Dear Customer:

Thank you for purchasing our product,we wish you satisfy our service,if you have any further questions or any quality issues, please show the belows number and don't hesitate to contact our Customer Service People:

202410