
Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance





- Do not clean furniture with harsh cleansers or polish.
- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- Stains may be removed with mild soap solution and damp cloth.
- ✓ Keep away from sources of ignition.
 - ✓ Oust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in the Seat Panel for hardware packs.

CLUB CHAIR



CAUTION: This Chair is NOT a TOY

Keep your child / children at bay during the assembly process. For turning the Chair and to prevent damage to the Chair, 02 adults may be needed to execute this action

Part List:


T GIT Elot.				
Label	Picture	Description	Qty	
А	Le de de de la constante de la	Backrest Panel	1	
В	and the same of th	Left Arm Panel	1	
С	and a second	Right Arm Panel	1	

D		Seat Panel	1	
E		Back Cushion	1	
F		Seat Cushion	1	
<u>Hardware</u>				
Label	Picture	Description	Qty	
1		Bolt (M6x35mm) + Extra 1 pc	5	
2		Bolt (M6x40mm) + Extra 1 pc	9	
3		Flat washer (17x7x1mm) + Extra 1 pc	13	

Assembly Preparation


Before Beginning Assembly:













Allen wrench





4

1






















• Save all packaging until finished.


Assembly Steps Overview Backrest Panel (A) Right Arm Panel (C) Left Arm Panel (B) Seat Panel (D) FRONT FACING Back Cushion (E) Seat Cushion (F)

This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Club chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise the parts and steps before assembly.




Unpack and place all the parts on a clean, non-marring surface.

FRONT FACING




Fix the right arm panel C with the seat panel D by using bolts ②, flat washers ③, and the allen wrench ④. **Do not fully tighten the bolts.**




With your adult partner's help, turn over the frame. Using bolts 2, flat washers 3, and the allen wrench 4 to fix the backrest panel A with the frame in Step 2 at the connection of the seat panel D and the backrest panel A. **Do not fully tighten the bolts.**

Step 4:




At the intersection of the right arm panel C and the backrest panel A, by using bolts ①, flat washers ③, and the allen wrench ④ to fix the frame. **Do not fully tighten the bolts.**






Using bolts ②, flat washers ③, and the allen wrench ④ to connect the left arm panel B to the frame in Step 4. **Do not fully tighten the bolts.**



Using bolts ①, flat washers ③, and the allen wrench ④ to fix the left arm panel B to the frame in Step 4. Fully tighten all the bolts in this chair frame.



With your adult partner's help, turn over the chair frame in Step 5. Put the seat cushion F, which has 2 velcro tapes, on the chair frame. Put the back cushion E on the seat cushion F.

