


Instruction Manual


















Instruction Manual

Please save this manual for future reference.


Thank you for purchasing this product. This product has been manufactured with the highest standards of safety and quality.

Product Name:	Carved Accent Cabinet With 4 Doors
SKU #:	W2295P246504-H0100E

hardwares contents:


CONTENTS					
ID	DESCRIPTION	QTY	ID	DESCRIPTION	QTY
A	 Allen Wrench	1	B	 Allen Wrench	1
C	 8*65 Screws	2	D	 8*45 Screws	6
	 Washer			 Washer	
E	 8*35 Screws	10	F	 Screws 3 . 5 *20	42
	 Washer				
H1	 Screws 3*12	8	H2	 Magnetic door touch	4
I	 Door Handle	4	J	 Cabinet feet	4
	 4*30Screws				
	 Washer				

Step 1




Attached the cabinet legs(J) to the cabinet bottom

Step 2




Insert side panels to the bottom. Align and tighten screws & washer by Allen wrench

Step 3




Insert shelf board to the side panel. Align and tighten screws & washer by Allen wrench

Step 4




Install the doors to the bottom and the side panel.

Step 5




Attach the top of the cabinet. Align and tighten screws & washer by Allen wrench

Step 6




Align back panel and screw in.

Step 7




Install the Magnetic door touch and screw in. To ensure additional stability, Anti-tip furniture restraint kit is included.

Step 8



Enjoy your cabinet



Important:

Tighten each bolt nuts firmly. DO NOT over tighten any of the bolt nuts as this may strip the screws. DO NOT sit or stand on the table as this may damage the product and cause serious bodily injury.