Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST				
ITEM	DESCRIPTION	BOX	QTY	
A	HEADBOARD	1	1 PC	
В	FOOTBOARD	2	1 PC	
С	SIDE RAIL	2	2 PCS	
D	CENTER RAIL	2	1 PC	
E	CENTER SUPPORT LEG	2	3 PCS	
F	BED SLAT	1	1 SET	
G	METAL SUPPORT	3	2 PCS	
Н	METAL LEG	3	2 PCS	

HARDWARE LIST (BOX : 2)				
ITEM	DESCRIPTION	QTY		
1	JCBB BOLT M8 x 30mm accord	16 PCS		
2	JCBB BOLT M8 x 20mm (BLACK)	4 PCS		
3	WOOD SCREW M4 x 32mm	9 PCS		
4	WOOD SCREW M4 x 20mm	2 PCS		
5	M5 ALLEN KEY (BALL SHAPE)	1 PC		





