


## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**224841Q(B1-B3)**  
***Queen Bed***

# ITEM: 224841Q(B1-B3)



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

25 MINUTES

## PARTS IDENTIFICATION






### B1 (BOX 1)

A	HEADBOARD PANEL		1PC	B	LEFT HEADBOARD LEG		1PC
C	RIGHT HEADBOARD LEG		1PC	D	HEADBOARD BOTTOM RAIL		1PC

### B2 (BOX 2)

E	FOOTBOARD		1PC
---	-----------	---	-----

### B3 (BOX 3)

F	BED RAIL		2PCS	G	BED SLAT		4PCS
H	BED SLAT SUPPORT WITH LEVELER		4PCS				
HB	224841Q(B1) FROM BOX 1 HEADBOARD COMPLETE		1PC	E	224841Q(B2) FROM BOX 2 FOOTBOARD		1PC

# ITEM: 224841Q(B1-B3)



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.










### WARNING!






1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

## HARDWARE IDENTIFICATION

### Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 224841Q(B1)

1	<b>SHORT BOLT</b> (Ø1/4" x 38MM - BLK)		2PCS
2	<b>SMALL LOCK WASHER</b> (Ø1/4" x 10 x 2MM - BLK)		2PCS
3	<b>SMALL FLAT WASHER</b> (Ø1/4" x 19 x 2MM - BLK)		2PCS
4	<b>LONG BOLT</b> (Ø5/16" x 45MM - BLK)		6PCS
5	<b>BIG LOCK WASHER</b> (Ø5/16" x 12 x 2MM - BLK)		6PCS
6	<b>BIG FLAT WASHER</b> (Ø5/16" x 19 x 2MM - BLK)		6PCS
7	<b>ALLEN WRENCH</b> (M4 x 58MM - BLK)		1PC

### Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 224841Q(B2)

8	<b>THREADED BOLT</b> (Ø5/16" x 90MM - BLK)		8PCS
9	<b>NYLON WASHER</b> (26 x 12 x 8MM - BLK)		8PCS
10	<b>HEX NUT</b> (Ø5/16 x 6MM - BLK)		8PCS
11	<b>WRENCH</b> (12MM - BLK)		1PC
12	<b>PAN HEAD SCREW</b> (Ø8 x 25MM - BLK)		8PCS

### NOTE:


Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

# ITEM: 224841Q(B1-B3)




## ASSEMBLY INSTRUCTIONS

### STEP 1



### STEP 2




ITEM: **224841Q(B1-B3)**




## ASSEMBLY INSTRUCTIONS

### STEP 3




### STEP 4 **COMPLETE**



ITEM: **224841Q(B1-B3)**




Inner Size : 59.75"W X 82.00"D



Note: Dimension tolerance  $\pm 5\%$

*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**224842**  
**Nightstand**

ITEM: **224842**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B FRONT LEG



2PCS

C BACK LEFT LEG



1PC

D BACK RIGHT LEG



1PC

## HARDWARE IDENTIFICATION

1 BOLT  
( $\Phi 5/16"$  x 45mm - BLK)



8PCS

2 LOCK WASHER  
( $\Phi 5/16"$  x 12 x 2MM - BLK)



8PCS

3 FLAT WASHER  
( $\Phi 5/16"$  x 19 x 2MM - BLK)



8PCS

4 ALLEN WRENCH  
(M4 x 58MM - BLK)



1PC




ITEM: **224842**




## ASSEMBLY INSTRUCTIONS

### STEP 1



### STEP 2



### COMPLETE



**ASSEMBLY INSTRUCTIONS****ANTI-TIPPING INSTALLMENT INSTRUCTIONS  
FURNITURE TIPPING RESTRAINT****WARNING**

Injury may result from tipping furniture.  
This restraint may protect against tipping furniture.  
Do not allow children to climb on furniture.  
This restraint is not a substitute for proper adult supervision.  
Failure to detach this restraint before moving the furniture may result in injury and damage.


1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
7. To double lock return the beaded end back through the keyhole as shown.
8. Check to make sure the cable tie is securely laced and locked to the brackets.



ITEM: **224842**



Inner Size of Drawer : 21.50"W X 13.00"D X 6.50"H X 0.50"T



Note: Dimension tolerance  $\pm 5\%$

**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**224843**  
***Dresser***

ITEM: **224843**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A DRESSER



1PC

B FRONT LEG



2PCS

C BACK LEFT LEG



1PC

D BACK RIGHT LEG



1PC

E CENTER SUPPORT  
LEG WITH LEVELER



1PC

## HARDWARE IDENTIFICATION

1 BOLT  
(Φ5/16" x 45mm - BLK)



8PCS

2 LOCK WASHER  
(Φ 5/16" x 12 x 2MM - BLK)



8PCS

3 FLAT WASHER  
(Φ5/16" x 19 x 2MM - BLK)



8PCS

4 ALLEN WRENCH  
(M4 x 58MM - BLK)




1PC

ITEM: **224843**

## ASSEMBLY INSTRUCTIONS

### STEP 1




### STEP 2 COMPLETE



**ASSEMBLY INSTRUCTIONS****ANTI-TIPPING INSTALLMENT INSTRUCTIONS  
FURNITURE TIPPING RESTRAINT****WARNING**

Injury may result from tipping furniture.  
This restraint may protect against tipping furniture.  
Do not allow children to climb on furniture.  
This restraint is not a substitute for proper adult supervision.  
Failure to detach this restraint before moving the furniture may result in injury and damage.


1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
7. To double lock return the beaded end back through the keyhole as shown.
8. Check to make sure the cable tie is securely laced and locked to the brackets.



ITEM: **224843**




Inner Size of Drawer : 27.25"W X 13.00"D X 7.00"H X 0.50"T



Note: Dimension tolerance  $\pm 5\%$



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**224844**  
***Mirror***

ITEM: **224844**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A	<b>DRESSER FROM BOX ITEM# 224843</b>		1PC
B	<b>MIRROR</b>		1PC
C	<b>MIRROR SUPPORT (PACKED WITH DRESSER)</b>		2PCS

## HARDWARE IDENTIFICATION


1	<b>BOLT (Φ1/4" x 38mm - BLK)</b>		6PCS
2	<b>LOCK WASHER (Φ1/4" x 10 x 2MM - BLK)</b>		6PCS
3	<b>FLAT WASHER (Φ1/4" x 19 x 2MM - BLK)</b>		6PCS
4	<b>ALLEN WRENCH (M4 x 58MM - BLK)</b>		1PC

ITEM: **224844**

## ASSEMBLY INSTRUCTIONS




### STEP 1




### STEP 2

**COMPLETE**



ITEM: **224844**



**Note: Dimension tolerance  $\pm 5\%$**