


ASSEMBLY INSTRUCTION

STORAGE BENCH




N715P293344

IMPORTANT NOTE :

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP

Detail View


















Please read these instructions fully before starting assembly:

1. Check you have all the components and tools listed on the following pages.
2. Remove all fittings from the plastic bags and separate them into their groups.
3. Keep children and animals away from the work area, small parts could choke if swallowed.
4. Make sure you have enough space to layout the parts before starting.
5. During assembly do not stand or put weight on the product, this could cause damage.
6. Assemble the item as close to its final position (in the same room) as possible.
7. Assemble on a soft level surface to avoid damaging the unit or your floor.
8. Parts of the assembly will be easier with 2 people.
9. To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.
10. Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
11. Regularly check and ensure That all bolts and fittings are tightend properly.
12. Please do not place items that exceed the load capacity.











Care and maintenance:

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


PART LIST





| | | | |
|---------------------------|---|------------------------------|---|
| 1 |  | 2 |  |
| CUSHION(1pc) | | TOP FRAME(1pc) | |
| 3 |  | 4 |  |
| BOTTOM SHEF (1pc) | | BACK FRAME (1pc) | |
| 5 |  | 6 |  |
| RIGHT SIDE FRAME (1pc) | | LEFT SIDE FRAME (1pc) | |
| 7 |  | 8 |  |
| FRONT FRAME(1pc) | | CENTER SUPPORT DRAWRE (2pcs) | |
| 9 |  | 10 |  |
| LEFT SUPPORT DRAWRE (1pc) | | RIGHT SUPPORT DRAWRE (1pc) | |
| 11 |  | 12 |  |
| LEGS (4pcs) | | FRONT DRAWER (3pcs) | |
| 13 |  | 14 |  |
| BACK DRAWER (3pcs) | | SIDE DRAWER (6pcs) | |
| 15 |  | | |
| BOTTOM DRAWER (3pcs) | | | |

HARDWARE LIST


| | | | |
|--|--|--|--|
| A  Ø1/4" x 35mm | B  Ø1/4"x11mm | C  Ø1/4"x19mm | D  4 mm |
| BOLT (8pcs) | SPRING WASHER (8pcs) | FLAT WASHER (8pcs) | ALLENKEY (1pc) |
| E  HOLES (2pcs) | F  FOLDED (1pc) | G  #4x15mm | H  #4x25mm |
| | | WOOD SCREW (20pcs) | WOOD SCREW (48pcs) |
| I  HANDLE (3pcs) | J Ø5/32x28mm  HANDLE BOLT (3pcs) | | |

Step 1








| | | | | | | | |
|---|----------|---|------|---|----------|---|------|
| A | Ø1/4"x35 |  | 4PCS | C | Ø1/4"x19 |  | 4PCS |
| B | Ø1/4"x11 |  | 4PCS | D | 4x58mm |  | 1PC |

Step 2




Step 3




| | | | | | | | |
|---|----------|---|------|---|----------|---|------|
| A | Ø1/4"x35 |  | 4PCS | C | Ø1/4"x19 |  | 4PCS |
| B | Ø1/4"x11 |  | 4PCS | D | 4x58mm |  | 1PC |

Step 4




Step 5




G

#4x15mm



4PCS

Step 6



G

#4x15mm




14PCS

E




2PCS

Step 7



G

#4x15mm




2PCS

F



1PC

Step 8




H

#4x25mm




24PCS

Step 9




H

#4x25mm



24PCS

Step 10



I



3PCS


J

Ø5/32x28mm



3PCS

Step 11



Complete

