

ASSEMBLY INSTRUCTIONS

MODEL: VIRDEN CHAIR

Read this instruction carefully. Remove all wrapping material, staples and straps from the carton. See hardware and furniture part list for guidance. Be sure you have all wooden furniture parts on a clean and flat soft surface, such as a carpet or rug, to prevent from being scratched.



- CAUTION:**
- 1. Do Not FULLY - TIGHTEN the nut or screw until all is ready to assemble.
 - 2. Do Not OVER - TIGHTEN the nut or screw to avoid causing damages to the tread.
 - 3. Keep all hardware part out reach of children.

Part List


No.	Description	Qty
A	Back rest	1 pc
B	Leg (L/R)	2 pcs
C	Front Rail	1 pc
D	Back Rail	1 pc
E	Seat Support	2 pcs
F	Seat	1 pc

Hardware List


No.	Description	Qty
1	JCBC M6 x 40mm	8 pcs
2	JCBC M6 x 30mm	8 pcs
3	Spring Washer M6	16 pcs
4	Allen Key M4 x 110mm	1 pc
5	Csk 32mm	4 pcs
6	Wood Button	4 pcs




Step 1



Step 2




Step 3




ASSEMBLY INSTRUCTIONS

Step 4



Step 5



Step 6

