


Assembly Instructions

HKGRBS014



Assembly Instructions

HKGRBS014

ASSEMBLY REQUIREMENT

1 PERSON ASSEMBLY | 25 MINUTES ASSEMBLY TIME (APPROXIMATE)

TOOLS REQUIRED: ALLEN WRENCH (PROVIDED)

ASSEMBLY REQUIREMENT

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts Checklist and ensure they are complete before you start assembling.

TIPS FOR ASSEMBLY

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior and finish of the furniture.
3. During assembly, do not over-tighten any fittings as this may cause damage.
4. **DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.**
5. Do not sit or stand on the partially assembled product, only use the product for which it is intended.

CARE AND USE

- Recommended for indoor and residential use only.
- Wipe with a soft, dry cloth. DO not use harsh abrasives or household cleaners as they may damage the finish.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.

Okeysen Bar Stools Limited Warranty

Okeysen bar stools are warranted from the date of purchase against failure due to material and workmanship as follows:

1 YEAR on component parts including screws, seat frame, seat cushion and rattan backrest.

To make a warranty claim, please contact Okeysen, provide model number, proof of purchase and description of the problem.










At it's option Okeysen will:


- a) Supply compatible components of current manufacture.
 - b) Send a new product if necessary, customer must return the original product to the warehouse.
- Return freight will be paid by Okeysen.

RETURN POLICY


Customers can request to return the item within 30 days of receiving it. Return freight will be paid by Okeysen.

PARTS CHECK LIST


 <p style="text-align: center;">Ax1</p>	 <p style="text-align: center;">Bx1</p>	 <p style="text-align: center;">Cx1</p>	 <p style="text-align: center;">Ex1</p>
 <p style="text-align: center;">Gx1</p>	 <p style="text-align: center;">Jx12 (M6x25mm)</p>	 <p style="text-align: center;">Jx8 (M6x18mm)</p>	 <p style="text-align: center;">Lx4</p>
 <p style="text-align: center;">Hx1</p>			




Step 1: Attach Back **E** to Seat **D** with Frames **Fx2** and Screws **Jx8** by Allen Wrench **H** as the picture.
Note: Do not tighten completely until all screws are in place.




Step 2: Place the Leg **A** under the Leg **B**.




Step 3: Attach Footring **G** to the Leg with Screws **Jx4** and finish with Allen Wrench **H**.
Note: Do not tighten completely until all screws are in place.



Step 4: Attach Tilt Mechanism **C** to the Leg with Screws **Kx4** by Allen Wrench **H**.



Step 5: Connect the Chair Leg and the Seat with Screws **Kx4** by Allen Wrench **H**.
Paste the Foot Pad **Lx4** to the bottom.



Step 6: Enjoy your new stools!

After-sales Support

We are working on delivering you a perfect product, but sometimes the parts may still be damaged or lost in transit.

If any parts are damaged or lost, please contact us immediately, perfect solutions will be offered to fix the issues.

CONTACT INFO: Support@Okeyesen-Global.com