





MANHATTAN COMFORT

BC003






STOP!


Before beginning the assembly process,
ensure all boxes and parts have been delivered.

FOR BEST RESULTS:

- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.



TOOLS REQUIRED



View our assembly video online:
WWW.MANHATTANCOMFORT.COM




Stuck? Question? We are here to help.
tel: 908-888-0818
e-mail: help@manhattancomfort.com

Support Site




Included in this package:

- A. TOP PANEL(1)
- B. BACK HORIZONTAL PANEL(2)
- C. FIXED SHELF PANEL (1)
- D. BOTTOM PANEL (1)
- E. BACK PANEL (1)
- F. LEFT PANEL (1)
- G. RIGHT PANEL (1)
- H. SHELF PANEL (3)




Hardware Identification


- ① KD BOLT - 28pcs
L=35mm




- ② KD CAM - 28pcs
Ø15*11mm




- ③ COVER CAP - 36pcs




- ④ WOOD DOWEL - 20pcs
Ø8*30mm




- ⑤ SHELF SUPPORT - 12pcs




- ⑥ STRAPS - 1pc



- ⑦ SCREW - 1pc
Ø4*18mm




- ⑧ SCREW - 1pc
Ø4*25mm




- ⑨ PLASTIC - 1pc




- ⑩ PLASTIC WEDGE - 16pcs




- ⑪ SCREW - 16pcs
Ø3*17mm




- ⑫ SCREW - 4pcs
Ø3*15mm






Step 1:

* Insert Twenty-Two KD BOLT (1) to the LEFT PANEL (F), RIGHT PANEL (G)



Step 2:


* Insert Six KD BOLT (1) to the TOP PANEL (A) and BOTTOM PANEL (D).




Step 3:

* Attach the BACK HORIZONTAL PANEL(B) to the TOP PANEL (A) by the Three KD CAM (2) , Three COVER CAP (3) and Two WOOD DOWEL (4) .


②





③



④




(3 PCS) (3 PCS) (2 PCS)




Step 4:

* Attach the BACK HORIZONTAL PANEL(B) to the BOTTOM PANEL (D) by the Three KD CAM (2) , Three COVER CAP (3) and Two WOOD DOWEL (4) .


②





③



④




(3 PCS) (3 PCS) (2 PCS)




Step 5:

* Attach the TOP PANEL(A), FIXED SHELF PANEL (C), BOTTOM PANEL (D) to the LEFT PANEL(F) by the Eleven KD CAM (2) , Eleven COVER CAP (3) and Eight WOOD DOWEL (4) .


②




③



④




(11 PCS) (11 PCS) (8 PCS)




Step 6:

* Insert the BACK PANEL (E).



Step 7:


* Attach the TOP PANEL(A), FIXED SHELF PANEL (C), BOTTOM PANEL (D) to the RIGHT PANEL(G) by the Eleven KD CAM (2) , Eleven COVER CAP (3) and Eight WOOD DOWEL (4) .



Step 8:


* Insert Sixteen PLASTIC WEDGE(10) and Sixteen SCREW(11) to the BACK PANEL (E). Use Screw(12) to fix BACK PANEL(E).

⑫




(4 PCS)

⑩




(16 PCS)

⑪




(16 PCS)






Step 9:

*Input Three SHELF PANEL(H) with Twelve SHELF SUPPORT(5) .



Step 10:

* Attach anti-tipping straps to the back of the stand.



Step 11:


1st- With your pencil, strike a mark through the center of the hole in the SAFETY STRAP.

2nd- Drill a 3/8" hole on the mark.


3rd- FURNITURE TIPPING RESTRAINT KIT (9) into the hole until it is even with the surface of the wall.

4th- Turn the LONG SCREW through the hole in the SAFETY STRAP and into the WALL ANCHOR.


NOTE: You will need to turn the LONG SCREW multiple turns to completely tighten and secure your unit.



(1 PC)



(1 PC)





WARRANTY POLICY

All Manhattan Comfort furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons. This warranty is valid in the United States of America and Canada.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are not intended for outdoor use.

THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the furniture.



319 Ridge Rd. Dayton, NJ 08810
908-888-0818