


ASSEMBLY INSTRUCTIONS

INSTRUCTIONS DE MONTAGE

7PCS DINNING SETS

N752P308327

N752P308328




ASSEMBLY INSTRUCTIONS

INSTRUCTIONS DE MONTAGE

DINING CHAIR


ENSEMBLE DE À MANGER

N752P308328






DETAIL VIEW

Vue Détaillée



Part List For One Chair: N752P308328

Liste des pièces


Part list: "D" Packing At SKU: N N752P308327	D 1PC  Seat Frame Dessus de la chair	
E 1PC  Chair Back Dossier de chaise	F 2PCS  Front Leg Jambe avant	


Hardware List For One Chair: N752P308328

Liste des matériel


① x 4PCS  Ø1/4 x 75mm	② x 10PCS  Ø1/4 x 13mm	③ x 10PCS  Ø1/4 x 19mm	④ x 1PC  4mm
BOLT BouLon	Spring Washer Rondelle elastique	Flat Washer Rondelle plates	Allen key Clé Allen
⑤ x 2PCS  Ø1/4 x 40mm	⑥ x 4PCS  Ø1/4 x 60mm		
BOLT BouLon	BOLT BouLon		

STEP 1: ÉTAPE



①	Ø1/4 x 75mm		4PCS	③	Ø1/4 x 19mm		6PCS
②	Ø1/4 x 13mm		6PCS	④	4mm		1PC
⑤	Ø1/4 x 40mm		2PCS				

STEP 2: ÉTAPE



⑥	Ø1/4 x 60mm		4PCS	③	Ø1/4 x 19mm		4PCS
②	Ø1/4 x 13mm		4PCS	④	4mm		1PC

STEP 3:

ÉTAPE

Note: level it, and tighten all hardware.

