


ASSEMBLY INSTRUCTIONS

INSTRUCTIONS DE MONTAGE

7PCS DINNING SETS

N752P308327


N752P308328



ASSEMBLY INSTRUCTIONS


INSTRUCTIONS DE MONTAGE

DINNING TABLE N752P308327







DETAIL VIEW

Vue Détaillée



Part List: N752P308327

Liste des pièces

A 1PC  Table top Dessus de la table	B 1PC  Leaf Top Dessus de feuille	C 4PCS  Table Legs Pied de table
Chair Top 4pcs Part list: "D" are detail of chair	D 1PC  Seat Frame Dessus de la chair	

Hardware List: N752P308327


Liste des matériel

① x 8PCS  Ø 5/16x80mm	② x 8PCS  Ø 5/16x13mm	③ x 8PCS  Ø 5/16x19mm	④ x 1PC  4mm
BOLT BouLon	Spring Washer Rondelle elastique	Flat Washer Rondelle plates	Allen key Clé Allen


STEP 1:

ÉTAPE

Remove block before assembly.
Retirer le bloc avant l'assemblage




STEP 2: **ÉTAPE**





1	Ø 5/16x80mm		8PCS	3	Ø 5/16x19mm		8PCS
2	Ø 5/16x13mm		8PCS	4	4mm		1PC

STEP 3: **ÉTAPE**



STEP 4:
ÉTAPE



STEP 5:
ÉTAPE

Note: Turn the table over, level it, and tighten all hardware.

