


ASSEMBLY INSTRUCTION

ITEM NO.N715P313522

Dining Table



ASSEMBLY INSTRUCTION

ITEM NO.N715P313522

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION

ITEM NO.N715P313522




ASSEMBLY INSTRUCTION

ITEM NO.N715P313522


Part List

(A)




MID-SECTION TABLE TOP (1pc)

(B)




SIDE-SECTION TABLE TOP (1pc)

(C)




UPPER PANEL (1pc)

(D)




CURVED TABLE LEG (4pcs)

(E)



CENTER SUPPORT LEG (1 pc)

(F)




BOTTOM BOARD (1pc)

ASSEMBLY INSTRUCTION

ITEM NO.N715P313522

Hardware List


①



Ø 5/16" x 45 mm

BOLT (14 pcs)

②



Ø 5/16" x 60 mm

BOLT (6 pcs)

③



Ø5/16" x 13 mm

LOCK WASHER (20 pcs)

④



Ø5/16" x 19 x 2 mm

FLAT WASHER (20 pcs)

⑤



4 mm

ALLEN KEY (1 pc)

⑥




Ø10 x 30 mm

WOOD DOWEL (1pc)


ASSEMBLY INSTRUCTION

ITEM NO.N715P313522

STEP 1:




STEP 2:



ASSEMBLY INSTRUCTION

ITEM NO.N715P313522


STEP 3:



This part of the slide rail can be moved, if the holes are not aligned during the assembly process please try to move the slide rail to the position shown in the figure end then assemble!

BOLT	LOCK WASHER	FLAT WASHER	ALLEN KEY
Ø 5/16" x 45 mm	Ø 5/16" x 13 mm	Ø 5/16" x 19 x 2 mm	4 mm
			
① x 8	③ x 8	④ x 8	⑤ x 1


STEP 4:



ASSEMBLY INSTRUCTION

ITEM NO.N715P313522

STEP 5:



COMPLETE

