
ASSEMBLY INSTRUCTIONS

ITEM NO. FB3051CST-SC-4PK





ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

PARTS LIST				
NO.	DIAGRAM	PART NAME	Q'Ty	
1		CHAIR BACK	1PC x4	
2		CUSHION SEAT	1PC x4	
3		LEG	2PCS x4	

HARDWARE LIST				
NO.	DIAGRAM	PART NAME	Q'Ty	
А		BOLT Ø1/4" x 1-1/2"	2PCS x4	
В		BOLT Ø1/4" x 2-3/8"	4PCS x4	
С		BOLT Ø1/4" x 3"	4PCS x4	
D		LOCK WASHER Ø1/4"	10PCS x4	
Е		FLAT WASHER Ø1/4" x 19mm	10PCS x4	
F		ALLEN KEY 4mm	1PC x4	







Do not tighten screws until completely assembled.

