

WARNING!!

Children have died from furniture tipover. Tip restraints have been included with this product; you must install the tip restraints according to these instructions in order to minimize the risk of furniture tipping.

NEVER allow children to climb or hang on furniture, including drawers or cabinet doors.

In addition to installing the restrains, to help prevent tip-over











1. **NEVER** put a TV or other heavy objects on top of this product".
2. Do not stand on the product

 WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none">-ALWAYS install anti-tip device provided.-NEVER put a TV on this product.-NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.-NEVER open more than one drawer at a time.-Place heaviest items in the lowest drawers. <p><i>This is a permanent label. Do not remove!</i></p>
	

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance


- ⊘  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ⊘  • Do not place furniture under direct sunlight.
- ⊘  • Do not place furniture near heating or cooling vents.
- ⊘  • Do not write on furniture without a padded barrier to protect the surface.
- ⊘  • Do not place furniture outside . For indoor use only.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ⊘  • Children should not climb or jump on the furniture.













- Dust and pick-up spills using a clean, non-colored, lint-free cloth.


















Please look in carton for hardware packs an legs.

SIDEBOARD




Parts List

Label	Picture	Description	QTY
A		Top Panel	1
B		Right Side Board	1
C		Middle Clapboard	1
D		Left Side Board	1
E		Back Board	1
F		Back Board	1
G		Slot	1
H		Bottom Panel	1
I		Door	4
J		Shelf Board	2

Hardwares			
Label	Picture	Description	QTY
①		Long Bolt (M8*60mm)	9
②		Short Bolt (M8*30mm)	4
③		Flat Washer	12
④		Screw(M4*16mm)	65
⑤		Push Latch	4
⑥		Hydraulic Door Hinge	4
⑦		Hydraulic Door Hinge	4
⑧		Backboard Buckle	9
⑨		Screw(M3*16mm)	9
⑩		Shelf Support Pin	9
⑪		Adjustable Leveling Glide	4
⑫		EVA mat	5
⑬		Wrench	1
Tipover Restraint Device Hardware			
⑭		Anti-tip Anchoring Strap	2
⑮		Expansion Plug	2
⑯		Long Screw (M4*40mm)	3
⑰		Short Screw (M4*12mm)	3

Assembly Preparation

Before
Begining
Assembly:



①		x9	⑨		x9
②		x4	⑩		x9
③		x12	⑪		x4
④		x65	⑫		x5
⑤		x4	⑬		x1
⑥		x5	⑭		x2
⑦		x5	⑮		x2
⑧		x9	⑯		x3
			⑰		x3



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This sideboard has multiple parts and may require up to some 45 minutes to assemble. To give you an overview of the sideboard parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Attach push latch (5) to the top panel (A) with screw (4).

Step 2



Attach the right side board (B), left side board (D) to the top panel (A) with long bolt (1) and flat washer (3). ATTENTION: All the grooves must stay in one side (backside)


Step 3



Attach the middle clashboard (C) to the top panel(A) with short bolt(②)and flat washer(③).


Step 4

Notch facing down




Insert the back board (F) to the grooves. ATTENTION: Notch facing down.

Step 5




Insert the slot (G) and back board (E) to the grooves.

Step 6




Align the bottom panel (H) to the middle clapboard (C)、right side board(B) and left side board(D)

Step 7



Attach the bottom panel (H) to the middle clapboard (C)、right side board(B) and left side board(D) with long bolt(①)and flat washer(③).



Step 8



Fix the middle clapboard (C) with short bolt (②) and flat washer (③). Screw adjustable leveling glide (⑪) to bottom panel (H).


Step 9

 ⑩x8




Stand the mounted sideboard up, and insert shelf support pin (⑩) into each panel hole.

Step10




Put the shelf board(J) on the shelf support pin(⑩)

Step 11





Install the hydraulic door hinge(⑥) on the middle doors (I) and hydraulic door hinge(⑦) on the side doors (I) with screw(④), and stick the EVA mat (⑫) on the corner of the doors.

Step 12




Attach hydraulic door hinge(⑥), hydraulic door hinge(⑦) of the doors to sideboard body with screw(④).


Step13



Up and down
adjustment




Front and back
adjustment



Left and right
adjustment

Adjust the hydraulic door hinge(⑥) &(⑦) to make sure the doors in the same level



Step14



⑧x8


⑨x8

⑬x1




Insert backboard buckle (⑧) along the backboard and fix with screw(⑨)

Step15




Place the sideboard against the wall. Mark the positions for the expansion screws on the wall.

Step16




Drill holes on the wall in marking position, insert expansion plugs(⑮) into the holes, align with the expansion plugs (⑮), install the short side of anti-tip anchoring strap (⑭) with long screw(⑯).

Step17



Attach the long side of anti-tip anchoring strap (14) to the right side board(B) & left side board(D) with short screw(17).

Step18



The sideboard is ready for use.

”Questions & Answers about Proposition 65

- What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm. These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals.

Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water.

Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

- What types of chemicals are on the Proposition 65 list?

The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust. ”