




ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

703500

2PC COFFEE TABLE SET

REVISION 0: 06/30/2025

ITEM:703500



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intend for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A BIG TABLE TOP

1PC



C SMALL TABLE TOP


1PC



B2 (BOX 2)


B BIG TABLE BASE

1PC



D SMALL TABLE BASE


1PC



HARDWARE IDENTIFICATION

1 BOLT

1/4"x1"



10PCS

2 SPRING WASHER

1/4"



10PCS

3 WASHER



10PCS

4 ALLEN KEY

1/4"



1PC


Hardware pack is located in 703500B2

ITEM:703500

ASSEMBLY INSTRUCTIONS




STEP 1



1		5 PCS
2		5 PCS
3		5 PCS
4		1 PC


STEP 2 COMPLETE



1		5 PCS
2		5 PCS
3		5 PCS
4		1 PC

ITEM:703500

ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$