



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

**610524PP
POWER LIFT RECLINER**


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION




PARTS LIST

A	BACK CUSHION	1PC
B	BASE	1PC
C	LEFT EAR	1PC
D	RIGHT EAR	1PC
E	PLUG-IN POWER SUPPLY	1PC
F	CONTROLLER	1PC


Z	HARDWARE PACKAGE		
NO	DESCRIPTION	FIGURE	QTY
1	SUBASSEMBLY OF FALLING BACKWARD PREVENTION		2PCS
2	BUTTERFLY NUT 1/4"		4PCS
3	HEXAGON BOLT 1/4" * 38mm		4PCS

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2





STEP 3



STEP 4



STEP 5




ASSEMBLY INSTRUCTIONS

STEP 6




STEP 7



STEP 8





STEP 9



STEP 10





USER'S ATTENTION

Before using chair, please clear and remove the obstacles before or behind this product to keep enough space for function operation. It is forbidden to force the movement.

The operation should be prohibited when this product is in the following position :

