ASSEMBLY INSTRUCTIONS

NOTE:50% TIGHTEN BEFORE FIXING ALL BOLTS

N704P331024K

Thank you for choosing our products.

1. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution.


Recommendations Before Beginning Assembly

- Read instructions, cover to cover
- † Have 2-4 adults on hand for assembly depending on product size
- Do not assemble directly on flooring or carpet
- Assemble on a clean non-marring surface (example: packing foam)
- Save all packaging until finished

3. Assembly Notice:

- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the hardware spill in the box.
- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- IMPORTANT: When setting up your product, DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING. Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

 Care & Maintenance




Stains may be removed with mild soap solution and damp cloth


Children should not climb or jump on the furniture

Dust and pick-up spills using a clean, non-colored, lint-free cloth

Caution

- This product contains small components. Please ensure that they are kept away from small children.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.








	1	1	
① x 1pc	② x 1pc	③ x 1pc	④ x 1pc
	00000	0 0 0	
⑤ x 1pc	⑥ x 2pcs	⑦ x 4pcs	® x 4pcs
			0
9 x 2pcs	① x 2pcs	① x 1pc	12 x 2pcs
· · · · · ·			
①3 x 1pc	14 x 1pc	15) x 1pc	16 x 1pc
W		Real Control of the C	R
① x 1pc	(18) x 1pc	19 x 2pcs	20 x 1pc
	Re-		
21) x 1pc	22 x 1pc	② x 2pcs	24) x 2pcs
	0 0 0		· · · · · · · · · · · · · · · · · · ·
25 x 2pcs	26 x 4pcs	② x 2pcs	28 x 1pc
	Q		
29 x 1pc	30 x 3pcs	③1) x 3pcs	32) x 1pc
33 x 2pcs	34) x 1pc	35 x 1pc	36 x 1pc
37) x 1pc	38 x 1pc	39 x 1pc	40 x 1pc
		6	
41) x 2pcs	42 x 1pc	43 x 1pc	


5-29

M6x35mm	Ф15х9mm В х 106pcs	Φ6x30mm	M3x12mm
A x 106pcs	D X TOOPCS	C x 84pcs	D x 30pcs
	CLx1 CRx1 DLx1 Ogs Ogs DRx1		M3x16mm
E x 1pc	F x 3pcs	G x 1pc	H x 22pcs
M4x45mm	ly Appa	M4x14mm	M4x35mm
I x 11pcs	J x 4pcs	K x 30pcs	L x 18pcs
I	√ M4x18mm	M4x22mm	
M x 5pcs	N x 10pcs	O x 15pcs	P x 2pcs
Q x 2pcs	R x 8pcs	S x 8pcs	T x 1pc
	⊕ M6x40mm		
U x 12pcs	V x 8pcs	W x 8pcs	X x 4pcs
0			
Y x 2pcs	Z x 1pc		

























































	M4x14mm	
A x 14	K x 2	Px2









A x 8	B x 8



B x 6	C x 6







æ B


STEP 16


B


⊕


















STEP 21 Α ľΑ 13 M4x35mm A x 2 B x 2 L x 4 STEP 22 (11) \bigcirc 0 0

















		M4x35mm		
8 x A	B x 8	L x 8	M x 2	N x 4
	20-29			




21-29







	M4x14mm		
J x 4	K x 8	M x 2	N x 4


22-29




C x 2 V x 4 W x 4 T x 1














M3x16mm	M4x14mm	V v 2	7 v 1
		0	




M3x16mm	M4x14mm
H x 6	K x 1




If the top of the door is not level with the side panel, loosen the screw at the back of the hinge as shown, then move the hinge in or out until the desired gap is achieved, and then re-tighten the back screw.




If the top of the door is not level with the side panel, loosen the screw at the back of the hinge as shown, then move the hinge in or out until the desired gap is achieved, and then re-tighten the back screw as shown.



If the gap is too tight between the two doors, loosen the screw at the front of the hinge as shown to make the adjustment and then re-tighten the screw.



If the gap is too tight between the two doors, loosen the screw at the front of the hinge as shown to make the adjustment and then re-tighten the screw.



- a) If the doors are not leveled with each other, loosen the screws (installed on STEP 31) at the Panel Wing of the hinge, then adjust the hinge up or down until the desired level or when both doors are leveled, and then retighten the screws.
- b) When all the desired positions are in place, use the remaining sixteen Screw (K) to fasten the Wing Panel using the balance two screw holes on Panel Wing.