



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

504664
SOFA

ITEM : 504664

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A SOFA



1PC

B LAF BACK CUSHION



1PC

C MIDDLE BACK CUSHION




1PC

D RAF BACK CUSHION



1PC

E LEG




5PCS

ITEM : 504664


ASSEMBLY INSTRUCTIONS




STEP 1





STEP 2



STEP 3




STEP 4



ITEM : 504664

ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$