





Read this instruction carefully. See hardware and furniture part list for guidance.
Be sure all parts are complete before assembly. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.
Follow the figure to start assembling.


PART LIST			
ITEM	DESCRIPTION	BOX	QTY
A	SEAT	1	1 PC
B	LEG	1	1 PC

HARDWARE LIST (BOX : 1)			
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 30mm		4 PCS
2	M6 FLAT WASHER		4 PCS
3	M6 SPRING WASHER		4 PCS
4	M4 ALLEN KEY (BALL SHAPE)		1 PC


CAUTION : 1. Do not FULLY - TIGHTEN the nuts or nut bolts until they are ready for assembly.
2. Do not OVER - TIGHTEN the nuts or bolts to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.
Tools needed : Screwdriver (not provided).

STEP 1



STEP 2



STEP 3

