

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

722833
TV STAND

ITEM:722833



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

60 MINUTES


MAX TV SIZE : 85"

PARTS IDENTIFICATION


A LEFT SIDE PANEL 1 PC




B RIGHT SIDE PANEL 1 PC




C LEFT DIVIDER PANEL 1 PC




D RIGHT DIVIDER PANEL 1 PC




E LEFT DECORATIVE STRIP 1 PC




F RIGHT DECORATIVE STRIP 1 PC




G BOTTOM PANEL 1 PC




H UPPER DECORATIVE STRIP 1 PC




I TOP PANEL 1 PC




J ADJUSTABLE SHELF 2 PCS




K MIDDLE BACK PANEL 2 PCS



L SIDE BACK PANEL 2 PCS




M BOTTOM LONG CROSSBAR 2 PCS



N BOTTOM SHORT CROSSBAR 2 PCS











O LED FIREPLACE 1 PC



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **722833****HARDWARE IDENTIFICATION****Z**




NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	6	PIN FOR ADJUSTABLE SHELF Ø4.9x8mm SR		8 PCS
2	WOODEN DOWEL Ø8 x 30mm		30 PCS	7	HANDLE SCREW ø3x15mm BLK		7 PCS
3	CAM BOLT Ø7 x 35.5mm SR		17 PCS	8	PLASTIC COVER Ø 52mm		2 PCS
4	CAM LOCK Ø15 x 12mm SR		17 PCS	9	STICKER Ø20mm		3 PCS
5	SCREW Ø 4.5x42mm SR		24 PCS				

Z8 not included in blister packaging.**NOTE:**





Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **722833**




STEP 1



STEP 2



INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: **722833**

COASTER
FINE FURNITURE

STEP 3




STEP 4





ITEM: **722833**

STEP 5

COASTER
FINE FURNITURE





STEP 6






ITEM: **722833**

COASTER
FINE FURNITURE

STEP 7




STEP 8




ITEM: **722833**

COASTER
FINE FURNITURE

STEP 9





STEP 10






ITEM: **722833**

COASTER
FINE FURNITURE

STEP 11




STEP 12




ITEM: **722833**

COASTER
FINE FURNITURE

STEP 13






STEP 14




ITEM: **722833**

STEP 15

COASTER
FINE FURNITURE



STEP 16





ITEM: **722833**




STEP 17

COMPLETE



ITEM: 722833



Note : Dimension tolerance $\pm 5\%$