

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

706347
END TABLE

ITEM:706347

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1 PC

B SIDE PANEL



2 PCS

C MIDDLE CROSS
PANEL



1 PC

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	WOODEN DOWEL Ø8x30mm		10 PCS	4	PLASTIC FEET Ø15mm		4 PCS
2	CAM BOLT Ø7x35.5mm SR		10 PCS	5	STICKER Ø20mm		2 PC
3	CAM LOCK Ø15x12mm SR		10 PCS				



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.





ITEM: **706347**

COASTER
FINE FURNITURE


STEP 1



STEP 2



INCORRECT
CORRECT







Apply glue on all wooden dowels to ensure integrity of the structure.





ITEM: 706347

COASTER
FINE FURNITURE

STEP 3






STEP 4




ITEM: **706347**

STEP 5

COMPLETE



ITEM: **706347**



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

706348
LIFT TOP COFFEE TABLE

ITEM:706348

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

60 MINUTES


PARTS IDENTIFICATION

A SIDE PANEL




2 PCS

B LEFT DIVIDER
PANEL




1 PC

C RIGHT DIVIDER
PANEL




1 PC

D FRONT TOP BAR




2 PCS

E CROSS PANEL




1 PC

F TOP PANEL



1 PC

G CROSSBAR












1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:706348

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	8	SPRING BLK		2 PCS
2	WOODEN DOWEL Ø8 x 30mm		32 PCS	9	BOLT Ø5.8x16mm BLK		12 PCS
3	CAM BOLT Ø7 x 35.5mm SR		20 PCS	10	BOLT M6x28mm BLK		4 PCS
4	CAM LOCK Ø15 x 12mm SR		20 PCS	11	BOLT M6x19mm BLK		4 PCS
5	LONG SCREW Ø 4.5x42mm SR		6 PCS	12	ALLEN WRENCH 4mm SR		1 PC
6	PLASTIC FEET Ø15mm		4 PCS	13	STICKER Ø20mm		4 PCS
7	LIFTER BLK		1 SET				

Z7 not included in blister packaging.









NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **706348**

STEP 1

COASTER
FINE FURNITURE



INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **706348**


STEP 2



COASTER®
FINE FURNITURE





STEP 3






ITEM: **706348**

COASTER
FINE FURNITURE

STEP 4








STEP 5







ITEM: **706348**

COASTER
FINE FURNITURE

STEP 6





STEP 7






ITEM: **706348**

STEP 8

COASTER
FINE FURNITURE






STEP 9






ITEM: **706348**

STEP 10

COASTER
FINE FURNITURE






STEP 11





ITEM: **706348**

STEP 12

COMPLETE



ITEM: 706348



Note : Dimension tolerance $\pm 5\%$