





ASSEMBLY INSTRUCTION

ITEM NO: 194S9725BEG/BRW/GRY-1SW

SWIVEL GLIDER RECLINING CHAIR


NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.

COMPONENT LIST (CHAIR)

NO.	DRAWING	QTY	DESCRIPTION
A		1	CHAIR BASE
B		1	BACK REST
C		1	LSF EAR
D		1	RSF EAR


STEP# 1

Put the Back rest(B) to the Chair base (A).




STEP# 2

Put the LSF EAR (C) & RSF EAR (D) to the Back rest (B).



COMPLETED



Care Instruction for Textured Microfiber Furniture.

In order to maintain the original appearance of your Textured Microfiber Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage Textured Microfiber.
- Do not place your Textured furniture too close to windows, radiators, or vents.
- Vacuum or wipe with a soft brush to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connections are tight, Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.