










# ASSEMBLY INSTRUCTION


## ITEM NO:194S9688GY-CR

### CORNER SEAT

LEGS, HARDWARE, BACK CUSHION ARE STORED IN THE BOTTOM OF THE SEAT, PLEASE TAKE OUT FOR ASSEMBLY.

NO.	PARTS LIST	QTY	DESCRIPTION
A		1	Seat Frame
B		1	Seat Cushion
C		2	Headrest
D		1	Back Cushion
E		1	Back Cushion
F		2	Pillow
G		4	Wooden Leg
H		4	Washer
I		2	Connector

#### STEP 1:




# ASSEMBLY INSTRUCTION



## ITEM NO: 194S9688GY-CR

### CORNER SEAT

#### STEP 2:



#### STEP 3 (Completed) :






#### CARE INSTRUCTION FOR FABRIC FURNITURE

In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.


°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.

°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.

# ASSEMBLY INSTRUCTION

NO.	PARTS LIST	QTY	DESCRIPTION
A		2	AC
B		2	CR
C		1	4-Ottoman

STEP 1 :



STEP 2 (Completed) :

