







# Instruction




**Double Lounge Chaise**

## Product List

<b>Part A</b>  Left - side Lounge Chaise 1PC	<b>Part B</b>  Right- side Lounge Chaise 1PC	<b>Part C</b>  Backrest Pillow 2PCS	<b>Part D</b>  Throw Pillow 2PCS	<b>Part E</b>  Unpacking Tool 1PC
----------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------

## Operation Guide


### Step 1



Use a box cutter or scissors to carefully open the outer cardboard box. Avoid cutting too deeply to prevent damaging the contents inside.

### Step 2


**Tear off it**



Carefully peel off the sealing tape from the package. Then, unwrap and remove the outer winding film that secures the product.


### Step 3

**Open it**



Use the Part E unpacking tool to open the compressed vacuum film. Be careful not to scratch the fabric.

### Step 4



Place the sofa in a well-ventilated area and allow it to expand to their original shape. This process may take 72 hours. Avoid sitting on them during this period.