Assembly Instructions

CAUTION: You must read these Assembly Instructions before you proceed.




SAFETY WARNING

Never adjust chaise lounge or recliner backrest while seated.

Always make sure the backrest is flat before moving the chaise lounge.

Keep all limbs clear from under the backrest when it is in a raised position.


Serious finger, hand, or other bodily injuries may result from adjusting the chaise lounge backrest position while seated.




The examples pictured above are non exhaustive and are for your reference only

Care & Maintenance











Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



 To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



• Do not write on furniture without a padded barrier to protect the surface.



 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Stains may be removed with mild soap solution and damp cloth.




Keep away from sources of ignition.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Lounge Chaise



CAUTION: This Lounge Chaise is NOT a TOY.

Keep your children at bay during the assembly process.

For turning the Lounge Chaise and to prevent damage to the Lounge Chaise 02 persons may be needed to execute this action

Parts List:


Label	Picture	Description	QTY
А		Footboard Frame	1
В		Middle Frame	1
С		Headboard Frame	1
D		Vertical Legs 1	2
E		Vertical Legs 2	2
F		Vertical Legs 3	2
G		Horizontal legs	2
Н		Horizontal legs	1

Hardware:

Label	Picture	Description	QTY
		(1/4*40mm) Bolts	9
2		(1/4*13*1mm) Spring Washer Rings	9
3		(1/4*14*1.5mm) Flat Washer Rings	9
4		Left side iron bass	1
5		Right side iron bass	1
6	(1)))))))))>	(Ø4*20mm) Screws	9
7	(+)	(Ø4*40mm) Screws	7
8	(+)	(Ø4*50mm) Screws	19
9		(4.5*58mm) Allen Wrench	1
10		Assembly Tools Required (Not Included)	1

Assembly Preparation:

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-


Assembly Preparation:




This Lounge chaise has multiple parts and may require up to some 60 minutes to assemble. To give you an overview of the Lounge chaise parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Attach the headboard frame (C) to the middle frame (B) and footboard frame (A) together by using Bolts (1); Spring Washers (2) and Flat Washers (3) with Allen Wrench (9).




Attach the Vertical Legs 3 (F) to the Horizontal legs (G) by using screws (7) with Assembly Tools Required (Not Included) (10).




Attach the Vertical Legs 1 (D) to the Horizontal legs (H) by using screws (7) with Assembly Tools Required (Not Included) (10).


Step 4



Attach the iron bass left (4) and right (5) side to the frame of step 2. by using screws (6) with Assembly Tools Required (Not Included) (10).



Attach the frames of step 2 and 3 into the Vertical Legs 2 (E) by using screws (8) with Assembly Tools Required (Not Included) (10).



Adjust the backrest to an angle you feel comfortable.

Caution: Be careful when folding backrest to avoid the finger strapped at the folding joint.

Your Lounge Chaise is ready for use.