

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

192923
Bench

ITEM:192923



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.









ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	SEAT		1PC
B	APRON		2PCS
C	LEG FRAME		2PCS
D	CROSSBAR		1PC

HARDWARE IDENTIFICATION

1	SHORT BOLT (M6 x 60mm - BLK)		2PCS
2	LONG BOLT (M6 x 100mm - BLK)		4PCS
3	BARREL NUT (M6 x Ø 12mm - Zink)		6PCS
4	WOOD DOWEL (M8 x 30mm)		6PCS
5	ALLEN WRENCH (M4 x 100mm - BLK)		1PC
6	FLAT HEAD SCREW (M4 x 32mm - RBW)		12PCS


NOTE:

Philips head screw driver is required in the assembly process; however, manufacture does not provide this item.


ITEM: **192923**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2



** Place the nut into the end hole

STEP 3




ITEM: **192923**



ASSEMBLY INSTRUCTIONS

STEP 4


COASTER
FINE FURNITURE



STEP 5 COMPLETE



ITEM:192923



Note : Dimension tolerance $\pm 5\%$