


Assembly Instruction


Coffee table




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.








Do not use power tools to assemble products. Its use may cause damage to this product.









Parts List







Parts List





Number	Name	Part	Qty
1	Desktop		X1 PC
2	Upper box		X1 PC
3	Middle surface		X1 PC
4	Middle frame		X1 PC
5	Bottom surface		X1 PC
6	Bottom frame		X1 PC
7	Leg of a table		X4 PC

Hardware List



Number	Hardware	Part	Qty
A	6x30		4+1 PCS
B	6x16		12+1 PCS
C	ALLEN KEY		1 PC
D	6x16		20+1 PCS
E	6x35		8+1 PCS
F	Adjustable feet		4+1 PCS

1










A	6x30 	4 PCS
B	6x16 	8 PCS
C	ALLEN KEY 	1 PC
D	6x16 	12 PCS


2




3




F	Adjustable feet 	4 PCS
B	6x16 	4 PCS
C	ALLEN KEY 	1 PC
D	6x16 	8 PCS
E	6x35 	4 PCS



4



Flip to face
up from the front



Fasten all screws, including step 1.

E	6x35 	4 PCS
C	ALLEN KEY 	1 PC
D	6x16 	4 PCS