

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

192921 *Dining Table*

REVISION 0: 05/20/2025

PAGE 1 OF 3

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A TOP 1PC

B LEG 4PCS

C LEAF 2PCS

HARDWARE IDENTIFICATION

1	BOLT (M8 x 70mm - BLK)	8PCS
2	LOCK WASHER (M8 - BLK)	8PCS
3	FLAT WASHER (M8 - BLK)	8PCS
4	ALLEN WRENCH (M5 x 65MM - BLK)	1PC
5	METAL PLATE 3.5 (2 HOLE)	4PCS
6	PAN HEAD SCREW (M3.5 x 16mm - BLK)	8PCS


NOTE:

Philips head screw driver is required in the assembly process; however, manufacture does not provide this item.


ASSEMBLY INSTRUCTIONS

STEP 1







STEP 2




STEP 3









Note: Dimension tolerance ± 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

192922 Side Chair

REVISION 0 : 05/20/2025 PAGE 1 OF 7 COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME		1PC
В	RIGHT FRONT LEG	Big&Small Hole Marking	1PC
С	LEFT FRONT LEG		1PC
D	RIGHT SIDE STRETCHER	Small Hole Marking	1PC
E	LEFT SIDE STRETCHER	Big Hole Marking	1PC
F	MIDDLE STRETCHER		1PC
G	SEAT FRAME		1PC
н	WOODEN SEAT		1PC

NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 7

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

1	SHORT FLAT HEAD SCREW (M4 x 32mm - RBW)	<i>⊕mmm</i> >	6PCS
2	LONG FLAT HEAD SCREW (M4 x 35mm - RBW)	\(\)	6PCS
3	SHORT BOLT (M6 x 35mm - BLK)		1PC
4	MEDIUM BOLT (M6 x 60mm - BLK)		2PCS
5	LONG BOLT (M6 x 70mm - BLK)		4PCS
6	LOCK WASHER (1/4"- BLK)		7PCS
7	FLAT WASHER (1/4"- BLK)		7PCS
8	ALLEN WRENCH (M4 x 110MM)		1PC

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


COASTER

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS STEP 1



STEP 2




PAGE 4 OF 6


ASSEMBLY INSTRUCTIONS








STEP 4




ASSEMBLY INSTRUCTIONS

STEP 5






STEP 6



PAGE 6 OF 6

COASTERFURNITURE.COM





Note: Dimension tolerance ± 5%