


ASSEMBLY INSTRUCTION
30INCH BATH VANTINY (COMBO)
SKU: N759P313314





Thank you for purchasing this quality product. Be sure to check all pack material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


***Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
***Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

1. Note: This is not a clothing storage cabinet and it is not recommended to use it as a clothing storage cabinet.
2. All cabinets come with TRD, stainless steel or our "L-Bracket "when shipped.

Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions















	<p>Diagram A</p>	<p>Insert Cam Bolt into hole as shown in diagram A.</p>
	<p>Diagram B</p>	<p>Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.</p>
	<p>Diagram C</p>	<p>Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.</p>
<p>Connect the panels together.</p>		
<p>ARROW SIGN</p> <p>Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.</p>		
<p>To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i></p>		

Detail View - CABINET

















Identifying the Hardware -Identify the hardware using the illustrations below.

Part List


1		2	
	Top Side Panel (L) - 1pc		Mid Panel - 1pc
3		4	
	Top Side Panel (R) - 1pc		Bottom Side Panel (L) - 1pc
5		6	
	Bottom Side Panel (R) - 1pc		Bottom Panel Rear - 1pc
7		8	
	Top Panel Rear - 1pc		Mid Panel - 1pc
9		10	
	Base Frame - 1pc		Cabinet Feet - 4pcs
11		12	
	Cabinet Door - 1pc		Door side panel(L) - 1pc
13		14	
	Door side panel(R) - 1pc		Round Bar - 2pc

Part List

15	 Door shelf panel - 2pc	16	 Bottom Panel (Bottom Drawer) - 1pc
17	 Drawer Side Panel (L) (Bottom & Mid Drawer) - 2pcs	18	 Drawer Side Panel (R) (Bottom & Mid Drawer) - 2pcs
19	 Back Panel (Bottom Drawer) - 1pc	20	 Support Bar (Bottom Drawer) - 1pc
21	 Bottom Drawer Face - 1pc	22	 Bottom Panel (Top & Mid Drawer) - 2pcs
23	 Back Panel (Mid Drawer) - 1pc	24	 Mid Drawer Face - 1pc
25	 Side Panel (L) (Top Drawer) - 1pc	26	 Side Panel (R) (Top Drawer) - 1pc
27	 Back Panel (Top Drawer) - 1pc	28	 Top Drawer Face - 1pc


Part List

29




Crossbar Front - 1pc

30


















Front Top Bar - 1pc

31









Sink - 1pc

Hardware List


A	 ø6x35mm Three in one bolts - 37pcs	B	 ø14.5x12mm Three in one lock - 37pcs	C	 ø8xø4x32mm Round head screw - 25pcs
D	 ø8xø4x25mm Round head screw - 3pcs	E	 ø13x1/4"x40mm Hex-Head bolts - 4pcs	F	 ø1/4"x16x1mm Washer - 4pcs
G	 4mm Allen key - 1pc	H	 ø25x25mm Handle - 5pcs	I	 ø5/32"x19mm Handle screw - 2pcs
J	 ø5/32"x32mm Handle screw - 3pcs	K	 Damping hinge - 2pcs	L	 ø7xø3.5x15mm Flat head screw - 12pcs
M	 ø8x30mm Wood dowel - 36pcs	N	 ø6x30mm Wood dowel - 20pcs	O	 Anti fall hardware (2sets)


STEP: 1

G	A	E	F	M
				
1PC	4PCS	4PCS	4PCS	4PCS




STEP: 2

B

4PCS





STEP: 3

A




4PCS



Don't lean ×



Don't over tighten ×



STEP: 4

B




4PCS


M



4PCS





STEP: 5




A




8PCS





STEP: 6




A




11PCS




STEP: 7




A



2PCS



STEP: 8



B




2PCS

D





2PCS



M





1PC


STEP: 9

B	M
	
11PCS	7PCS







STEP: 10





B	M
	
8PCS	8PCS




STEP: 11




A**8PCS**


STEP: 12

B	K	L	M
			
8PCS	2PCS	4PCS	12PCS




STEP: 13


H	I	L
		
1PC	1PC	8PCS




Use the screws to adjust up or down




Use the screws to permanent








Use the screws to adjust left or right




Use the screws to adjust in or out








STEP: 14

C	N	H	I	J
				
8PCS	8PCS	2PCS	1PC	1PC







STEP: 15


N	C	H	J
			
4PCS	8PCS	1PC	1PC




STEP: 16






C	D	N
		
1PC	1PC	8PCS




STEP: 17





C	H	J
		
8PCS	1PC	1PC

STEP: 18



STEP: 19




STEP: 20

Install the sink on the cabinet with glue.

Let stand for 24 hours

(Installez l'évier sur le meuble avec de la colle.


Laissez reposer 24 heures)




*Silicone glue is not included
in the package to comply
with safety regulations in
certain shipping conditions.

*La colle silicone n'est pas incluse
dans le colis afin de respecter les
règles de sécurité dans certaines
conditions d'expédition.

STEP: 21



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

