
### **TABLE SET**

# Assembly Instructions - Please keep for future reference N844P285187



Important - Please read these instructions fully before starting assembly



### Safety and Care Advise

#### Important - Please read these instructions fully before starting assembly

Check you have all the components and tools listed on the following pages.

Remove all fittings from the plastic bags and separate them into their groups.

Keep children and animals away from the work area, small parts could choke if swallowed.

Make sure you have enough space to layout the parts before starting.

During assembly do not stand or put weight on the product. this could cause damage.

Assemble the item as dose to its final position (in the same room) as possible.

Assemble on a soft level surface to avoid damaging the unit or your floor.

Parts of the assembly will be easier with 2 people.

To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.



#### Care and maintenance

Only clean using a damp doth and mild detergent, do no use bleach or abrasive cleaners.

From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.

#### **Handly Hints**

Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts. Regularly check and ensure that all bolts and fittings are tightend properly.

### WARNING

In order to help prevent overturning please follow these instructions

To help prevent product toppling over please follow the below steps:

Use the anti tip strap or wall fixing method provided (if applicable)

Do not allow children to climb or hang on the furniture

Do not open more than one drawer at a time


Do not place heavy items in the top drawers


Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Please note that only the anti tip strap is provided.


You will need to provide wall plugs and screws applicable for your wall type.

### **ASSEMBLY INSTRUCTION**







### Part List (N844P285187)





### Hardware List (N844P285187) C Α В 1/4" x 12mm Horizontal -Hole bolts 21 pcs Ø8 x 30 mm Wood dowel 28 pcs 1/4" x 50mm Hex-Head bolts 12 pcs Ε D F Allen Key 1 pc 1/4" x 80mm Hex-Head bolts 9 pcs Cam Bolt 10 pcs G Н M3.5 x 15 mm Wood Screws 46 pcs Magnets 1 set Cam Lock 12mm 10 pcs K Plastic Wedges 12 pcs M3 x 12 mm Wood Screws 6 pcs USB Power Outlet 1 pc (2700mm) M Ν O 5/32" x 22 mm Truss Head Screw 3 pcs Handles 3 pcs Hinge - 2 pcs P R Shelf Pin 9mm 4 pcs M4 x 30 mm Wood Screws 8 pcs 1/4" x 30mm Hex-Head bolts 8 pcs S Antifall 2 set **Assembly Tools Required (Not Included)** Use this ruler to help correctlly identify the screws 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 The screws length is measured from the head to the point (35mm screw shown) 03/03/2025 6















Step 3:















## Step 5:










## Step 8:










## Step 10:
















## Step 14:

































## Step 23:






### Step 24:







**30** 

03/03/2025







# **FINISH**

