


STORAGE CABINET

Assembly Instructions - Please keep for future reference

SKU:N729P335558K



Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning –
please follow these instructions











To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than required.

(A)  Cam Bolt x 44	(B)  6*30mm Dowel x 53	(C)  Cam lock x 44	(D)  4*18mm Screw x 2
(E)  6*50mm Dowel x 4	(F)  4*40mm Screw x 50	(G)  4*20mm Handle x 4SET	(H)  3*12mm Screw x 8
(I)  Anti-fall accessories x2	(J)  Shelf support pin x 8	(K)  4*14mm Straight bend hinge x 8set	(M)  4*10mm Handle x 1 SET
(N)  4*35mm Screw x 4	(DR)  300mm runner x 1	(DL)  300mm runner x 1	(CR)  300mm runner x 1
(CL)  300mm runner x 1			


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note : ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.















4










Assembly Instructions



Assembly Instructions


1  1PC	2  1PC	3  1PC
4  1PC	5  1PC	6  1PC
7  2PC	8  1PC	9  1PC
10  1PC	11  2PC	12  1PC
13  1PC	14  1PC	15  1PC
16  8PC	17  1PC	18  1PC
19  1PC	20  1PC	21  1PC

Assembly Instructions


22  1PC	23  1PC	24  1PC
25  1PC	26  1PC	27  1PC
28  4PC	29  2PC	30  1PC
31  2PC	32  2PC	33  1PC
34  1PC	35	36

Assembly Instructions

Step 1




Step 2




Assembly Instructions

Step 3




Step 4



Assembly Instructions




Step 5



(A)	
Cam Bolt x4	
(B)	
6*30mm Dowel x 5	
(C)	
Cam lock x 4	



Assembly Instructions

Step 6





Assembly Instructions

Step 7




Step 8



Assembly Instructions




Step 9



(A)	
Cam Bolt x 6	
(B)	
6*30mm Dowel x 8	
(C)	
Cam lock x 3	
(F)	
4*40mm Screw x 10	

Assembly Instructions


Step 10




(H)	
3*12mm Screw x 4	
(CR)	
300mm runner x 1	
(CR)	
300mm runner x 1	
(B)	
6*30mm Dowel x 1	
(C)	
Cam lock x 3	

Assembly Instructions

Step 11





Step 12





Assembly Instructions

Step 13





Step 14





Assembly Instructions

Step 15




Step 16




Assembly Instructions

Step 17



Assembly Instructions

Step 17



Assembly Instructions

Step 19

K




4*14mm Straight bend hinge
x8set

G



4*20mm Handle x 4SET




Step 20

J




Shelf support pin x 8




Assembly Instructions

Step 21




Step 22



Assembly Instructions

Step 23



Assembly Instructions

Step 24

