Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



• Not for commercial use. For residential use only.



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



• Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



• Do not place furniture under direct sunlight.



• Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside. For indoor use only.



 Stains may be removed with mild soap solution and damp cloth.




• Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean,non-colored, lint-free cloth.

Please look in Seat frame for hardware packs and legs. Sets often ship in multiple boxes and may arrive a day or two apart.

DINING CHAIR



Parts List


Label	Picture	Description	QTY	
Α		H FRONT LEG	1	
В		BACK LEG WITH CUSHION	1	
С		LEFT SIDE RAIL	1	
D		RIGHT SIDE RAIL	1	
E		U FRAME	1	
F		CUSHION SEAT	1	
G	0 0	CORNER BLOCK	4	
Page 2 of 8				

<u>Hardware</u>


Label	Picture	Description	QTY
1		JCBC SCREW (M6*30MM)	16
2	(i)	JCBC SCREW (M6*45MM)	8
3		CSK SCREW (M4*32MM)	6
4		CSK SCREW (M4*45MM)	4
5		SPRING WASHER (M6)	8
6		WOOD DOWEL (M8*30MM)	4
7		ALLEN KEY (M4*100MM)	1
8		Screwdriver	Not Provided

Assembly Preparation

Before Beginning Assembly:









Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-

Assembly Steps




This Chair has multiple parts and may require to some 30 minutes to assemble. To give you an overview of the chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Page 5 of 8

Step 2




Place the H Front Leg (A),Back Leg With Cushion, On a clean, non marring surface. Install the Side Rail (C), Side Rail (D), into the hole with Wood Dowel ⑥ as pictured above.

Then Install the Left Side Rail (C),Right Side Rail (D), using JCBC Screw (M6*45mm) ②, Spring Washer (M6) ⑤, with Allen Key (M4*100mm) ⑦, as pictured above.

NOTE: Do not fully tighten the Bolts in this step.


Step 3



Install the U Frame (E), into H Front Leg (A), Back Leg With Cushion (B), as pictured above.


Then install U Frame (E),into H Front Leg (A) using CSK Screw (M4*45mm) ④, with Screwdriver ⑧, as pictured above.

Step 4




Place the assembled chair as shown.Install U Frame (E), Into Back Leg With Cushion (B) using CSK Screw (M4*45mm) ④, with Screwdriver ⑧, as pictured above.

Step 5




Place the assembled chair as shown. Install Cushion Seat (F) using CSK Screw (M4*32mm) ③ with Screw Driver ⑧ as pictured above.

Step 6



Place the assembled chair as shown. Install Corner Block (G) using JCBC Screw (M6*30mm) 1, with Allen Key (M4*100mm) 7 as pictured above. NOTE: Once the assembly is completed, proceed to tighten all Bolts sequentially.

Step 7



Place the chair on a LEVEL SURFACE to see if it wobbles.

CAUTION 1: When tightening the screws and bolts, tighten sequentially. If there are any wobbles after tightening, loosen the screws and bolts and execute this same process.

Ensure all screws and bolts are fully locked into position.

CAUTION 2: This chair can only be used on a flat, level surface.

Your Chair is ready for use.