Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



• Not for commercial use. For residential use only.



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



• Do not place furniture under direct sunlight.



• Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.



• Stains may be removed with mild soap solution and damp cloth.




Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in Seat frame for hardware packs and legs. Sets often ship in multiple boxes and may arrive a day or two apart.

DINING CHAIR




Parts List				
Label	Picture	Description	QTY	
А		Front Leg (R)	1	
В		Front Leg (L)	1	
С		Box Seat	1	
D		Chair Back	1	
E		Cushion Back	1	
F		Cushion Seat	1	

Hardware				
Label	Picture	Description	QTY	
1)		JCBC Screw (M6*90)	4	
2		JCBC Screw (M6*30)	1	
3		CSK Screw (M4*32)	7	
4		Hex Nut (M8)	4	
(5)	©	Spring Washer (M6)	5	
6		Spring Washer (M8)	4	
7		Flat Washer (M6)	4	
8		Flat Washer (M6*13)	1	
9		Flat Washer (M8)	4	
10		Wood Button (M14.5)	1	
(11)		Allen Key (M4)	Provided	
12		Y Spanner M5(13)	Provided	
13		Screwdriver	Not Provided	

Assembly Preparation

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.






Place all Parts on a clean, flat surface.

Step 2




Place the Chair back (D) on a clean, non marring surface. Install the Box Seat (C) into the Chair back (D) using JCBC Screw (M6*90mm) ①, Spring Washer (M6) ⑤, Flat Washer (M6) ⑦, with Allen Key (M4) ① as pictured above.

Step 3




Install both Right Front Legs (A) and Left Front Leg (B) consecutively on both sides into the Box Seat (C) using Hex Nut (M6) 4, Spring Washer (M8) 6, Flat Washer (M8) 9 with Y Spanner M5(13) 12 as pictured above.

Step 4




Install the Cushion Back (E) into Chair Back (D) using JCBC Screw (M6*30) ②,Spring Washer (M6)⑤ and Flat Washer (M6*13) ⑧ with Allen Key (M4) ① as pictured above.

Step 5




Place the assembled chair downside as shown. Install the Cushion Seat (F) onto the Box Seat (C) using CSK Screw (M4*32) (3) with Screwdriver (13) as pictured above.

Step 6



Place the chair right side up. Press the Wood Button (M14.5) 10 onto Chair Back D.

Step 7



Place the chair on a LEVEL SURFACE to see if it wobbles.

CAUTION 1: When tightening the screws and bolts, tighten sequentially. If there are any wobbles after tightening, loosen the screws and bolts and execute this same process.

Ensure all screws and bolts are fully locked into position.

CAUTION 2: This chair can only be used on a flat, level surface.

Your Chair is ready for use.