

Assembly Instructions


CAUTION: You must read these Assembly Instructions before you proceed.

Care & Maintenance







- ⊘  • Not for commercial use. For residential use only.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ✓  • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
- ⊘  • Children should not climb or jump on the furniture.
- ⊘  • Do not write on furniture without a padded barrier to protect the surface.
- ✓  • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ✓  • Keep away from sources of ignition.
- ✓  • Dust and pick-up spills using a clean, non-colored, lint- free cloth.

Please look in Seat Panel for hardware packs



DINING CHAIR



Parts List:


Label	Picture	Description	Qty
A		Left Leg Panel	1
B		Right Leg Panel	1
C		Seat Panel	1
D		Front Bar	1
E		Backrest Panel	1
F		Seat Cushion	1

Hardware:


No	Picture	Description	Qty
①		Allen Wrench	1
②		Bolt (M6*40mm)	7
③		Screw (M4*55mm)	3
④		Screw (M6*80mm)	3
⑤		Screwdriver	Not provided

Assembly Preparation:


Before Beginning Assembly:



A




B




C



D



E



F



x 1



x 7



x 3



x 3



Not provided



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps:

OVERVIEW:




This Dining Chair has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the Dining Chair, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.


Step 2



With assistance from you adult partner, attach Seat Panel (C) to Left Leg Panel (A) by using Bolts (②) and Allen Wrench (①). Then, attach Front Bar (D) to Left Leg Panel (A) by using Screw (③) and Screwdriver (⑤) as shown above.

DO NOT fully tighten the Screw and the Bolts.

Step 3




Place Right Leg Panel (B) facing down on a clean, non-marring surface. With assistance from you adult partner, attach the assembled part in Step 2 to Right Leg Panel (B) and then secure Seat Panel (A) to Right Leg Panel (B) by using Bolts (②) and Allen Wrench (①).

Then, secure Front Bar (D) to Right Leg Panel (B) by using Screw (③) and Screwdriver (⑤) as shown above.

DO NOT fully tighten the Screw and the Bolts.


Step 4



With assistance from your adult partner, attach Backrest Panel (E) to Seat Panel (C) of the assembled part in Step 3 by using Screws (④) and Allen Wrench (①) as shown above.

DO NOT fully tighten the Screws.

Step 5




With assistance from your adult partner, turn the assembled part in Step 4 right side up.

Then secure Backrest Panel (E) to Left Leg Panel (A) and Right Leg Panel (B) of the assembled part in Step 4 by using Bolts (②) and Allen Wrench (①) as shown above.

DO NOT fully tighten the Bolts.

Step 6



Inspect it and make sure all parts are adequately connected.

Gently and gracefully, sit onto the Dining Chair.

This will help to align all the parts at all joint areas.


Then get off the Dining Chair and proceed to tighten the Bolts and Screws in a sequential manner.

When tightening the Bolts, Screws tighten sequentially.

DO NOT tighten any Bolts, Screws fully and then move on towards the next one.

If there are still wobbles, loosen the Bolts, Screws and execute this same process.

Step 7



Place Seat Cushion (F) onto Seat Panel (A) and then tie the magic tape straps of Seat Cushion (F) to the slats of Seat Panel (A) as shown above.

Your Dining Chair is ready to use.

This Dining Chair can only be used on a flat, level surface.